FORKLIFT AND WORK MACHINES

SPARE PARTS CATALOGUE

Arslan Stack® Forklift

"Forklift Spare Parts Supplier"

CURTIS TURKEY
Authorized Dealaer

BOSCH INDUSTRIAL AUTOMOTIVE
Authorized Dealaer

O.S.B. Esenler Sanayi Sitesi 16 Blok No:9 Başakşehir/İstanbul

0(212) 549 58 00 - 01 0(546) 403 06 78

satinalma@arslanforklift.com

www.arslanforklift.com

ENGLISH

Stack®

Arslan

Forklift

"Forklift Spare Parts Supplier"

www.arslanforklift.com

ARSLAN İŞ VE İSTİF MAKİNALARI YEDEK PARÇA SAN. TİC. LTD. ŞTİ.

Arslan Forklift Company, which is known as Arslan Forklift Company, started to operate in the sector in 1995 and after providing service in the fields of forklift rental, maintenance and repair and spare parts supply for many years, it has accelerated the supply of spare parts and products in the field of forklifts, forklift equipment and stackers in 2010.

Curtis Our company is the brand Turkey main distributor, Zapi, SME, Albright APP Anderson Power, Rama, by supplying also the industry pioneer in a multi-brand products such as Danfoss to provide the Turkey market and the range of products continues to increase with each passing day...

(Some of the product brands and origins we supply ...)

İÇİNDEKİLER

ZAPI Kontrol..... 01
CURTIS Kontol..... 03
GE Kontrol..... 07
DANAHER Kontrol & SME Güç İnvertör 09
SEVCON Kontrol..... 10
OEM Kontrol..... 11
Diğer Kontrol Üniteleri & Programlayıcılar..... 13
Kontrol Ünitesi Soketli 14
IGBT Modülü..... 16
Albright Kontaktör & Tamir Kiti..... 17
GE Kontrol & Tamir Kiti 22
DC ZJ Kontaktör..... 25
NICHIYU Kontak..... 26
Lift Kontaktör..... 27
Linde Forklift Kontaktör & Tamir Kiti..... 28
HELI Forklift Motoru..... 29
HANGCHA Forklift Motoru..... 31
Diğer Motorlar..... 33
Forklift Direksiyon Motoru..... 35
Palet Sürüş Motoru..... 36
Lift Motoru..... 37
JAPAN Forklift Direksiyon Motoru..... 38
TOUR BUS Çekiş Motoru..... 39
Fırça Kutusu..... 40
Motor Yayları..... 41
Karbon Fırçalar..... 42
Enkoder..... 45
Kombinasyon Switch..... 47
Yön Switchi..... 50
Anahtar Switch / Ateşleme Switchi..... 52
Aydınlatma Switchi & REMA Acil Stop Switchi..... 54
Albright Acil Stop Switchi..... 55
Diğer Acil Stop Switchleri & Micro Switchler..... 56
Microswitch Soketli & Diğer Switchler..... 58
Flaş Işık..... 60
Tepe Lambaları..... 63
Sinyal Lambaları & Arka Stoplar..... 65
TOYOTA Forklift Lambaları..... 69

İÇİNDEKİLER

Ampül & Anderson Akü Soketleri..... 70
SMH Akü Soketleri..... 72
Akü Soket Tutamağı & Kontaklar..... 73
REMA AKü Soketleri..... 74
UMA Akü Soketleri..... 76
Diğer Akü Soketleri..... 77
AMP/MOLEX & Kablolar..... 78
Gaz Pedalları & Elektronik Throttle..... 79
İstif Kumanda Kolları..... 84
Akü Göstergeleri & Zaman Saatleri..... 85
Akü Şarj ve Şarj Ekipmanları..... 92
Diğer Elektronik Parçalar..... 97
Yürüyüş Ekipmanları & Elektrik Fren..... 101
Yürüyüş Tekerleri..... 103
Denge Tekerleri..... 106
Yük Tekerleri..... 108
Transpalet PU Tekerleri..... 112
PU Tekerlek Ekipmanları..... 113
Havalı Piston..... 114
Traksiyoner Aküler..... 115
Motor Tamir Kitleri..... 124
Marş Motorları..... 127
Alternator / Şarj Dinamosu..... 128
Distribütör / Karbüratör / Enjeksiyon Pompaları..... 129
Filtreler..... 130
Hidrolik Pompalar..... 131
Kontrol Valfleri..... 133
Orbitrol..... 135
Hidrolik Silindir & Radyatör..... 136
Su Pompaları / Devirdaim..... 139
Fan..... 140
Fren Merkezleri 141
Fren Pabuçları..... 145
Link & Link Pimleri..... 147
Akson..... 148
Akson Tamir Kitleri..... 149
Koltuklar..... 150
Gazlı Pistonlar..... 151

ZAPI Kontrol

◆ Seri Kontrol

▶H0 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.01.0423A1	A2H021	24	230

▶H1 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.01.1430A1	A2H132	24	300
A.B.04.01.1530A1	A4H132	48	300

▶H2B Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.01.2542A1	A4H248	48	400
A.B.04.01.2560A1	A4H268	48	600
A.B.04.01.2660A1	A8H268	80	600

www.arslanforklift.com

◆ AC Kontrol

▶AC–0 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.0415A1	AC–0	24	150
A.B.04.03.0420A1	AC–0	24	200

▶AC–1 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.1425A1	AC–1	24	250
A.B.04.03.1522A1	AC–1	36–48	220

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

ZAPI Kontrol

◆ AC Kontrol

▶ AC–2 INVERTER Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.3545A1	AC–2	48	450
A.B.04.03.3555A1	AC–2	48	550
A.B.04.03.3650A1	AC–2	80	500

▶ COMBI AC–1 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.5435A1	COMBI AC–1	24	350+350
A.B.04.03.5530A1	COMBI AC–1	48	300+300

▶ DUALAC2 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.6532A1	DUALAC2	36–48	320+320
A.B.04.03.6545A2	DUALAC2	36–48	450+450
A.B.04.03.6640A1	DUALAC2	80	400+400

▶ ACE0 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.7432A1	ACE0	24	320
A.B.04.03.7528A1	ACE0	36–48	280

▶ ACE2 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.03.8535A1	ACE2	36–48	350
A.B.04.03.8540A1	ACE2	36–48	400
A.B.04.03.8545A1	ACE2	36–48	450
A.B.04.03.8635A1	ACE2	80	350

www.arslanforklift.com

ZAPI Kontrol

◆ Lift Kontrol / EPS Kontrol

▶ HP Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.04.0535A1	HP	48	350
A.B.04.04.0550A1	HP	48	500
A.B.04.04.0680A1	HP	80	500

▶ EPS–DC Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.04.1503A1	EPS–DC	24–48	30
A.B.04.04.1505A1	EPS–DC0	24–36	50

▶ EPS–AC0 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.04.3405A2	EPS–AC0	24/36	50
A.B.04.04.2504A1	EPS–AC0	48	45

www.arslanforklift.com

CURTIS Kontrol

◆ Magnet Motor Kontrol

▶ 1212 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.01.1407A1	1212–2401	24	70
A.B.01.01.1409A1	1212P–2501	24	90

▶ 1228 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.01.6411A2	1228–2901	24	110

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

CURTIS Kontrol

◆ Seri Kontrol

▶1204M Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.02.0427A1	1204M-4201	24-36	275
A.B.01.02.0527A1	1204M-5203	36-48	275
A.B.01.02.0532A1	1204M-5305	36-48	325
A.B.01.02.0632A1	1204M-6301	48-72	325

▶1205M Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.02.1550A1	1205M-5603	36-48	500
A.B.01.02.1640A1	1205M-6B403	60-72	400

▶1221M Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.02.3655A1	1221M-6701	48-72	550

▶1207B Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.02.4425A1	1207B-4102	24	250
A.B.01.02.4430A1	1207B-5101	24	300

▶1215/1219 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.02.5550A1	1215-8307	36-48	500
A.B.01.02.5560A1	1219-8406	36-48	600

www.arslanforklift.com

CURTIS Kontrol

◆ Motor Kontrol

▶1243 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.03.0420A1	1243-4220	24-36	200
A.B.01.03.0430A1	1243-4320	24-36	300

▶1244 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.03.1550A1	1244-5561	36-48	500
A.B.01.03.1560A1	1244-5651	36-48	600
A.B.01.03.1660A1	1244-6661	48-84	600

▶1266 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.03.2527A1	1266A-5201	36-48	275
A.B.01.03.2535A1	1266R-5351	36-48	350

▶1268 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.03.3540A1	1268-5403	36-48	400

www.arslanforklift.com

◆ AC Kontrol

▶1230 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.0420A1	1230-2402	24	200

▶1232E Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.1418A1	1232E-2121	24	180
A.B.01.04.1425A1	1232E-2321	24	250

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

CURTIS Kontrol

◆ AC Kontrol

▶ 1234/1234E Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.2435A1	1234-2371	24	350
A.B.01.04.2535A2	1234-5371	36-48	350
A.B.01.04.2535A1	1234E-5321	36-48	350

▶ 1236/1236E Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.3545A1	1236E-5421	36-48	450
A.B.01.04.3545A3	1236-5401	36-48	450
A.B.01.04.3640A1	1236-6401	48-80	400

▶ 1238 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.4480A1	1238-4801	24-36	800
A.B.01.04.4565A1	1238-5601	36-48	650
A.B.01.04.4645A2	1238-6401	48-80	450
A.B.01.04.4655A1	1238-6501	48-80	550

www.arslanforklift.com

◆ Lift Kontrol / EPS Kontrol

▶ 1253 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.05.0440A1	1253C-4401	24-36	400
A.B.01.05.0560A1	1253-4804	48	600
A.B.01.05.0660A1	1253-8001	80	600

▶ EPS 1220 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.04.0404A1	1220-2201	24	40

GE Kontrol

◆ EV 100 Parçaları

▶ EV100 Controller Assembly(High Performance TT Card)

A.B.03.01.0205

▶ SCR Controller(High Performance TT Card)

A.B.03.11.0205

▶ Logic Card IC3645LXCDI TT

A.B.03.21.0105

▶ 2REC/5REC T90RIA120

A.B.03.21.0201

▶ EV100 259A5523P1

A.B.03.21.0301

▶ 171B3939G02(High Performance)

A.B.03.21.0405

www.arslanforklift.com

▶ EV100 259A9208PXCR

A.B.03.21.0501

▶ EV100 55-533424

A.B.03.21.1001

▶ EV100 158C3234G1

A.B.03.21.1201

▶ EV100 44A727009-G01

A.B.03.21.0601

▶ EV100 171B3954G1

A.B.03.21.0701

▶ EV100 171B3940G1

A.B.03.21.0901

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

GE Kontrol

◆ GE Kontrol

▶SX Controller

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.02.02.0545A1	SepEx Controller	IC3645SR4U454N4	48	450
A.B.02.02.0560A1	SepEx Controller	IC3645SR4W606N6	48	600
A.B.02.02.0645A1	SepEx Controller	IC3645SR7W455CH8	80	450

▶STAR Series Controller

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.02.04.2430G1	Series Excited Controller	START2624L300PG50S	24	300
A.B.02.04.3640G1	Series Excited Controller	START2636L400PG50S	36	400
A.B.02.04.4830G1	Series Excited Controller	START2648L300PG50S	48	300
A.B.02.04.4840G1	Series Excited Controller	START2648L400PG50S	48	400
A.B.02.04.4860G1	Series Excited Controller	START2648L600PG50S	48	600
A.B.02.04.8050G1	Series Excited Controller	START2680L500PG50S	80	500
.....	...		.....	.....

www.arslanforklift.com

▶STAR Lift Controller

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.02.05.2460G1	Lift Controller(3 Speed)	STARP2624L600PG50S30B	24	600
A.B.02.05.4860G2	Lift Controller(3 Speed)	STARP2648L600PG50S30B	48	600
A.B.02.05.4860G4	Lift Controller(4 Speed)	STARP2648L600PLNSS4	48	600
A.B.02.05.8060G1	Lift Controller(3 Speed)	STARP2680L600PG50S30B	80	600
A.B.02.05.8060G4	Lift Controller(4 Speed)	STARP2680L600PLNSS4	80	600

DANAHER Kontrol

◆ DANAHER Kontrol

▶ ACS Controller

AC SuperDrive from Danaher Motion is often used on HELI,Hangcha.
Please find following Model Number:

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.07.4810	AC Controller	ACS4810-350C	48	350
A.B.07.4815	AC Controller	ACS4815-525C	48	525
A.B.07.8015	AC Controller	ACS8015-330C	80	330
A.B.07.8020	AC Controller	ACS8020-440C	80	440
A.B.07.8025	AC Controller	ACS8025-550C	80	550

▶ VMC20 Controller

VMC20 is equipped on the electric cars with CANopen,including Forklift, Stacker, Construction Equipment etc.

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.07.9001	Controller Box	VMC20-C2	24-80	/

www.arslanforklift.com

SME Güç Inverter

◆ SME Güç Inverter

▶ Power Inverter

Receive signal from Logic Controller,transfers DC voltage into frequency and 3 phase
Motor will work according to the signals.

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.06.0101	Power Inverter	B00IV020B05	36/48	450
A.B.06.0105	Power Inverter	B00IV235B04	48	600
A.B.06.0115	Power Inverter	B00IV210B03	80	450

▶ Logic Controller

Receive control order,including forward,backward,lift etc.
Then motor works according to the orders.
The Logic Controller will control Drive Motor & Lift Motor, and operate Forklift

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.B.06.0130	Logic Controller	E00IV414B01	36/48	/
A.B.06.0132	Logic Controller	E00IV359B01	72/80	/

SEVCON Kontrol

◆ SEVCON Kontrol

▶ Drive Controller(SepEx)633T46101

A.B.05.0111A1

▶ Drive Controller(Series Excited)632T46218

A.B.05.0121A1

▶ Drive Controller(Series Excited)632T86223

A.B.05.0131A1

▶ Lift Controller 633T46504

A.B.05.0211A1

▶ Lift Controller 632P84522

A.B.05.0221A1

▶ AC Controller 634A44101

A.B.05.0115

www.arslanforklift.com

OEM Kontrol

◆ OEM Kontrol

▶1212 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.0409G1	1212	24	90

▶1204M Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.1432G1	1204M	24–36	325
A.B.01.10.1532G1	1204M	36–48	325

▶1205M Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.2550G1	1205M	36–48	500
A.B.01.10.2640G1	1205M	60–72	400

▶1207B Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.3430G1	1207B	24	300

▶1215/1219 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.4550G1	1215	36–48	500
A.B.01.10.4560G1	1219	36–48	600

▶1243 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.5420G1	1243	24–36	200

www.arslanforklift.com

OEM Kontrol

◆ OEM Kontrol

▶ 1244 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.6550G1	1244	36–48	500
A.B.01.10.6560G1	1244	36–48	600
A.B.01.10.6660G1	1244	48–84	600

▶ 1230 AC

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.6420G1	1230	24	200

▶ 1253 Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.01.10.9460G1	1253	24	600
A.B.01.10.9560G1	1253	48	600
A.B.01.10.9660G1	1253	80	600

▶ H2B Series

Part Number	Model Number	Voltage(V)	Current(A)
A.B.04.01.2542G1	H2G	48	400
A.B.04.01.2560G1	H2G	48	600
A.B.04.01.2660G1	H2G	80	600

www.arslanforklift.com

Diğer Kontrol Ünitesi & Programlayıcılar

Diğer Kontrol Ünitesi & Programlayıcılar

Liftstar Steering Controller

A.B.10.0101A1

MINI Liftstar Drive Controller

A.B.10.0201A1

Xilin AC Controller(24V/80A)

A.B.10.0320G1

Xilin Controller KEB48201X

A.B.10.0325G1

Nichiyu EPS Controller

A.B.10.0601G1

Noblift Board SI20



A.B.10.0501A1

www.arslanforklift.com

Programlayıcılar & El Setleri

CURTIS Handset 1313K-4331

A.B.20.0103

CURTIS Programmer 1309 USB

A.B.20.0201

ZAPI Handset(Original)

A.B.20.1001

ZAPI Handset(Copy Part)

A.B.20.1101

GE Handset(Original)

A.B.20.2001

GE Handset(Copy Part)

A.B.20.2101

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Kontrol Ünitesi Soketli

◆ Kontrol Ünitesi Soketli

▶1207 Controller

Controller: 1207B-4102 (24V/250A)
Walk Contactor: DC88B-317T

▶1215/1219 Controller



Controller: 1215-8307 (48V/500A)
Lift Controller: 1253-4804 (48V/600A)
Walk Contactor: DC182B-537T
Power Contactor: SW200-262

www.arslanforklift.com

▶1204M Controller

Controller: 1204M-5305 (48V/325A)
Walk Contactor: ZJQ648 (48V/300A)
Power Contactor: ZJ200D (48V/200A)

▶1205M Controller

Controller: 1205M-5603 (48V/500A)
Walk Contactor: ZJQ648 (48V/300A)
Power Contactor: ZJ400D (48V/400A)

Kontol Ünitesi Montajlı

◆ Kontrol Ünitesi Montajlı

▶1243 Controller

Controller: 1243-4220 (24-36/200A)
Power Contactor: SW80-6 (24V/100A)

▶1244 Controller



Controller: 1244-5651 (36-48V/600A)
Lift Controller: 1253-4804 (48V/600A)
Power Contactor: SW200-262 (48V/400A)*2只

www.arslanforklift.com

▶1230 Controller



Controller: 1230-2402 (24V/200A)
Power Contactor: SW80-6 (24V/100A)

▶1234 Controller

Controller: 1234-5371 (36-48V/350A)
Power Contactor: SW180B-108 (48V/200A)

IGBT Modülü

◆ IGBT Modülü

▶1D600A-030

A.B.08.0541A1

▶TSM002

A.B.08.0543A1

▶ETN36-030

A.B.08.0545A1

▶QM500HA-H

A.B.08.0546A1

▶CM100DU-12F

A.B.08.0547A1

▶CM400DU-5F

A.B.08.0549A1

www.arslanforklift.com

▶ET439

A.B.08.0561A1

▶1MI100-O25

A.B.08.0571G1

▶FM600TU-07A

A.B.08.0581G1

▶IGBT 2MBI100N-060

A.B.08.0202G1

▶TCM CM600HN-5F

A.B.08.0601G1

▶ TCM Light Board

A.B.08.0401G1

Albright Kontaktör & Tamir Kiti

◆ Albright Kontaktör & Tamir Kiti

▶ DC88 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0124A1	DC88 Albright Contactor	DC88B-317T	24	100
A.A.01.0136A1	DC88 Albright Contactor	DC88-5	36	100
A.A.01.0148A1	DC88 Albright Contactor	DC88B-360T	48	100

▶ DC88 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0124G1	DC88 Contactor	ZJWT100A	24	100
A.A.01.0136G1	DC88 Contactor	ZJWT100A	36	100
A.A.01.0148G1	DC88 Contactor	ZJWT100A	48	100
A.A.01.0160G1	DC88 Contactor	ZJWT100A	60	100
A.A.21.0188G1	DC88 Repair Kit	ZJWT100A	/	100

www.arslanforklift.com

▶ DC182 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0224A1	DC182 Albright Contactor	DC182-3	24	200
A.A.01.0248A1	DC182 Albright Contactor	DC182B-537T	48	200
A.A.01.0248A2	DC182 Albright Contactor	DC182B-7	48	200
A.A.01.0280A1	DC182 Albright Contactor	DC182B-581T	80	200

Albright Kontaktör & Tamir Kiti

◆ Albright Kontaktör & Tamir Kiti

▶DC182 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0212G1	DC182 Contactor	ZJWT200A	12	200
A.A.01.0224G1	DC182 Contactor	ZJWT200A	24	200
A.A.01.0236G1	DC182 Contactor	ZJWT200A	36	200
A.A.01.0248G1	DC182 Contactor	ZJWT200A	48	200
A.A.01.0280G1	DC182 Contactor	ZJWT200A	80	200
A.A.21.0282G1	DC182 Repair Kit	ZJWT200A	/	200

▶SW80 Series Contactor(Original Albright)

www.arslanforklift.com

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0324A1	Sw80 Albright Contactor	SW80-6	24	100
A.A.01.0324A2	SW80 Albright Contactor	SW80-164L	24	100
A.A.01.0336A1	SW80 Albright Contactor	SW80-8	36	100
A.A.01.0348A1	SW80 Albright Contactor	SW80B-156	48	100
A.A.01.0380A1	SW80 Albright Contactor	SW80-62	80	100

▶SW80 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0324G2	SW80 Contactor	ZJW100A	24	100
A.A.01.0336G1	SW80 Contactor	ZJW100A	36	100
A.A.01.0348G1	SW80 Contactor	ZJW100A	48	100
A.A.01.0360G1	SW80 Contactor	ZJW100A	60	100
A.A.01.0380G1	SW80 Contactor	ZJW100A	80	100
A.A.21.0380G1	SW80 Repair Kit	ZJW100A	/	100

Albright Kontaktör & Tamir Kiti

◆ Albright Kontaktör & Tamir Kiti

▶ SW180 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0424A1	SW180 Albright Contactor	SW180B-751	24	200
A.A.01.0448A1	SW180 Albright Contactor	SW180B-108	48	200
A.A.01.0480A1	SW180 Albright Contactor	SW180B-14	72/80	200
A.A.01.0480A2	SW180 Albright Contactor	SW180B-1151	80	200

▶ SW180 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0424G1	SW180 Contactor	ZJW200A	24	200
A.A.01.0436G1	SW180 Contactor	ZJW200A	36	200
A.A.01.0448G1	SW180 Contactor	ZJW200A	48	200
A.A.01.0460G1	SW180 Contactor	ZJW200A	60	200
A.A.01.0480G1	SW180 Contactor	ZJW200A	80	200
A.A.21.0480G1	SW180 Repair Kit	ZJW200A	/	200

www.arslanforklift.com

▶ SW200 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0524A1	SW200 Albright Contactor	SW200-336	24	400
A.A.01.0548A1	SW200 Albright Contactor	SW200-1	48	400
A.A.01.0548A2	SW200 Albright Contactor	SW200-262	48	400
A.A.01.0548A4	SW200 Albright Contactor	SW200N-494	48	400
A.A.01.0580A1	SW200 Albright Contactor	SW200-802	80	400
A.A.01.0580A2	SW200 Albright Contactor	SW200-583	80	400
A.A.21.0520A1	SW200 Repart Kit	SW200	/	400

Albright Kontaktör & Tamir Kiti

◆ Albright Kontaktör & Tamir Kiti

▶SW200 Series Contactor(Copy Part)

SKU			(V)	(A)
A.A.01.0524G1	SW200 Contactor	ZJW400D	24	400
A.A.01.0536G1	SW200 Contactor	ZJW400D	36	400
A.A.01.0548G1	SW200 Contactor	ZJW400DE	48	400
A.A.01.0548G2	SW200 Contactor	ZJW400D	48	400
A.A.01.0580G1	SW200 Contactor	ZJW400DE	80	400
A.A.01.0580G2	SW200 Contactor	ZJW400D	80	400
A.A.21.0520G1	SW200 Repair Kit	ZJW400A	/	400

▶SU280 Series Contactor(Original Albright)

www.arslanforklift.com

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.1836A1	SU280 Albright Contactor	SU280-1008	36	400
A.A.01.1848A1	SU280 Albright Contactor	SU280-1176	48	400
A.A.01.1848A2	SU280 Albright Contactor	SU280B-1268	48	400
A.A.01.1848A3	SU280 Albright Contactor	SU280B-1074P	48	400
A.A.01.1880A2	SU280 Albright Contactor	SU280B-1080P	80	400

▶SW181 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0624A1	SW181 Albright Contactor	SW181B-241T	24	24
A.A.01.0648A1	SW181 Albright Contactor	SW181B-245T	48	48
A.A.01.0680A1	SW181 Albright Contactor	SW181B-248T	80	80

Albright Kontaktör & Tamir Kiti

◆ Albright Kontaktör & Tamir Kiti

▶ SW181 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0624G1	SW181 Contactor	ZJWH200A	24	200
A.A.01.0636G1	SW181 Contactor	ZJWH200A	36	200
A.A.01.0648G1	SW181 Contactor	ZJWH200A	48	200
A.A.01.0680G1	SW181 Contactor	ZJWH200A	80	200
A.A.21.0681G1	SW181 Repair Kit	ZJWH200A	/	200

▶ SW82 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0724A1	SW82 Albright Contactor	SW82-3/90P	24	100
A.A.01.0736A2	SW82 Albright Contactor	SW82-6	36	100
A.A.01.0748A1	SW82 Albright Contactor	SW82-157P	48	100

www.arslanforklift.com

▶ SW82 Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0724G1	SW82 Contactor	ZJW100A-2	24	100
A.A.01.0736G1	SW82 Contactor	ZJW100A-2	36	100
A.A.01.0748G1	SW82 Contactor	ZJW100A-2	48	100

▶ SW210 Series Contactor(Original Albright)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.01.0824A1	SW210 Albright Contactor	SW210-4	24	400
A.A.01.0848A1	SW210 Albright Contactor	SW210-129(normal close)	48	400
A.A.01.0872A1	SW210 Albright Contactor	SW210-132(normal close)	72	400

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

GE Kontaktör & Tamir Kiti

◆ GE Kontaktör & Tamir Kiti

▶GE304 Series(Original GE)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0124A1	GE304 Contactor	IC4482CTTA304FR124XN	24	300
A.A.02.0148A1	GE304 Contactor	IC4482CTTA304FR248XN	48	300
A.A.02.0196A1	GE304 Contactor	IC4482CTTA304FR196XN	96	300
A.A.22.0130A1	GE Repair Kit	GE304	/	300

▶GE304 Series(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0124G1	GE304 Contactor	ZJQ624	24	300
A.A.02.0136G1	GE304 Contactor	ZJQ636P	36	300
A.A.02.0148G1	GE304 Contactor	ZJQ648P	48	300
A.A.02.0160G1	GE304 Contactor	ZJQ660P	60	300
A.A.02.0172G1	GE304 Contactor	ZJQ672	72	300
A.A.02.0180G1	GE304 Contactor	ZJQ680	80	300
A.A.02.0196G1	GE304 Contactor	ZJQ696	96	300
A.A.22.0130G1	GE304 Repair Kit	GE304	/	300

www.arslanforklift.com

▶GE154 Series(Original GE)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0224A1	GE154 Contactor	IC4482CTTA154FR124XN	24	150
A.A.02.0248A1	GE154 Contactor	IC4482CTTA154FR248XN	48	150

GE Kontaktör & Tamir Kiti

◆ GE Kontaktör & Tamir Kiti

▶ GE154 Series(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0224G1	GE154 Contactor	ZJQ324	24	150
A.A.02.0248G1	GE154 Contactor	ZJQ348	48	150
A.A.02.0280G1	GE154 Contactor	ZJQ380	80	150
A.A.22.0215G1	GE154 Repair Kit	GE154	/	150

▶ GE300 Series(Original GE)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0324A1	GE300 Albright Contactor	IC4482CTTA300AH124XN	24	300
A.A.02.0348A1	GE300 Albright Contactor	IC4482CTTA300AH248XN	48	300
A.A.02.0380A1	GE300 Albright Contactor	IC4482CTTA300AH176XN	72/80	300
A.A.22.0330A1	GE300 Repair Kit	GE300	/	300

www.arslanforklift.com

▶ GE300 Series(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0324G1	GE300 Contactor	ZJQ424	24	300
A.A.02.0336G1	GE300 Contactor	ZJQ436P	36	300
A.A.02.0348G1	GE300 Contactor	ZJQ448	48	300
A.A.02.0380G1	GE300 Contactor	ZJQ480P	80	300
A.A.22.0330G1	GE300 Repair Kit	GE300	/	300

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

GE Kontaktör & Tamir Kiti

◆ GE Kontaktör & Tamir Kiti

▶GE150 Series(Original GE/Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0424A1	GE150 Albright Contactor	IC4482CTTA150AH124XN	24	150
A.A.02.0424G1	GE150 Contactor	ZJQ124	24	150
A.A.02.0448G1	GE150 Contactor	ZJQ148	48	150
A.A.22.0415G1	GE150 Repair Kit	GE150	/	150

▶GE100 Series(Original GE/Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0524A1	GE100 Albright Contactor	IC4482CTTA100AH124XN	24	100
A.A.02.0524G1	GE100 Contactor	ZJQ1024	24	100
A.A.02.0548A1	GE100 Albright Contactor	IC4482CTTA100AH248XN	48	100
A.A.02.0548G1	GE100 Contactor	ZJQ1048	48	100
A.A.02.0580A1	GE100 Albright Contactor	IC4482CTTA100AH176XN	72/80	100
A.A.02.0580G1	GE100 Contactor	ZJQ1080	80	100
A.A.22.0510G1	GE Repair Kit	GE100	/	100

www.arslanforklift.com

▶ZJQ2**/ZJQ5** Series Contactor(Copy Part)

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.02.0624G1	GE151 Contactor	ZJQ224	24	150
A.A.02.0648G1	GE151 Contactor	ZJQ248	48	150
A.A.02.0724G1	GE301 Contactor	ZJQ524	24	300
A.A.02.0736G1	GE301 Contactor	ZJQ536	36	300
A.A.02.0748G1	GE301 Contactor	ZJQ548	48	300

DC Kontaktör

◆ ZJ Model Kontaktör

▶ ZJ50 Series Contactor

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.03.0512G1	ZJ Model Contactor	ZJ50A	12	50
A.A.03.0524G1	ZJ Model Contactor	ZJ50A	24	50
A.A.03.0536G1	ZJ Model Contactor	ZJ50A	36	50
A.A.03.0548G1	ZJ Model Contactor	ZJ50A	48	50
A.A.03.0572G1	ZJ Model Contactor	ZJ50A	72	50

▶ ZJ100 Series Contactor

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.03.1012G1	ZJ Model Contactor	ZJ100D	12	100
A.A.03.1024G1	ZJ Model Contactor	ZJ100D	24	100
A.A.03.1036G1	ZJ Model Contactor	ZJ100D	36	100
A.A.03.1048G1	ZJ Model Contactor	ZJ100D	48	100
A.A.03.1060G1	ZJ Model Contactor	ZJ100D	60	100
A.A.03.1072G1	ZJ Model Contactor	ZJ100D	72	100
A.A.03.1080G1	ZJ Model Contactor	ZJ100D	80	100

www.arslanforklift.com

▶ ZJ200 Series Contactor

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.03.2012G1	ZJ Model Contactor	ZJ200D	12	200
A.A.03.2024G1	ZJ Model Contactor	ZJ200D	24	200
A.A.03.2036G1	ZJ Model Contactor	ZJ200D	36	200
A.A.03.2048G1	ZJ Model Contactor	ZJ200D	48	200
A.A.03.2060G1	ZJ Model Contactor	ZJ200D	60	200
A.A.03.2072G1	ZJ Model Contactor	ZJ200D	72	200

DC Kontaktör

◆ ZJ Model Kontaktör

▶ZJ400 Series Contactor

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.03.4012G1	ZJ Model Contactor(12V)	ZJ400D	12	400
A.A.03.4024G1	ZJ Model Contactor(24V)	ZJ400D	24	400
A.A.03.4036G1	ZJ Model Contactor(36V)	ZJ400D	36	400
A.A.03.4048G1	ZJ Model Contactor(48V)	ZJ400D	48	400
A.A.03.4048G2	ZJ Model Contactor(48V)	ZJ400DE	48	400
A.A.03.4060G1	ZJ Model Contactor(60V)	ZJ400D	60	400
A.A.03.4072G1	ZJ Model Contactor(72V)	ZJ400D	72	400

▶ZJ600 Series Contactor

Part Number	Part Name	Model Number	Voltage(V)	Current(A)
A.A.03.6012G1	ZJ Model Contactor(12V)	ZJ600D	12	600
A.A.03.6024G1	ZJ Model Contactor(24V)	ZJ600D	24	600
A.A.03.6048G2	ZJ Model Contactor(48V)	ZJ600DE	48	600

www.arslanforklift.com

NICHIYU Kontakt

◆ NICHIYU Kontakt

▶100A Single Contact

Part Number: A.A.26.0110G1

▶200A Single Contact

Part Number: A.A.26.0220G1

▶100A Double Contact

Part Number: A.A.26.1110G1

▶200A Double Contact

Part Number: A.A.26.1220G1

Lift Kontaktör

◆ Lift Kontaktör

▶ Lift Contactor

Part Number	Model Number	Voltage
A.A.04.0112G1	W800801-1	12V
A.A.04.0124G1	W800801-2	24V

▶ Lift Contactor

Part Number	Model Number	Voltage
A.A.04.0212G1	QDC2B-200A(DY)	12V
A.A.04.0212G2	QCC15-200A	12V
A.A.04.0224G1	QDC2B-200A(DY)	24V
A.A.04.0224G2	QCC15-200A	24V

www.arslanforklift.com

▶ Lift Contactor

Part Number	Model Number	Voltage
A.A.04.0224G3	ARD1353	24V

▶ Lift Contactor

Part Number	Model Number	Voltage
A.A.04.0412A1	Hrdro-Tek/original	12V
A.A.04.0424A1	Hrdro-Tek/original	24V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Linde Forklift Kontaktör & Tamir Kiti

◆ Linde Forklift Kontaktör & Tamir Kiti

▶Linde Contactor

Part Number	Part Name	Model Number	Linde P/N	Voltage	Current
A.A.05.0124A1	Linde Contactor	DC88B-513	7915495575	24	100
A.A.05.0124G1	Copy Linde Contactor	ZJWT100L	7915495575	24	100
A.A.05.0224A1	Linde Contactor	DC182B-726L	0009763545	24	200
A.A.05.0248A1	Linde Contactor	DC182B-733	0009763547	48	200
A.A.05.0248G1	Copy Linde Contactor	ZJWT200L	0009763512	48	200
A.A.05.0280A1	Linde Contactor	DC182B-698	0009763504	80	200
A.A.05.0280G1	Copy Linde Contactor	ZJWT200L	0009763504	80	200
A.A.25.0218A1	Linde Repair Kit	DC182B	0009414006	/	200
A.A.25.0218G1	Copy Repair Kit	ZJWT200L	0009414006	/	200

www.arslanforklift.com

▶Linde Contactor

Part Number	Part Name	Model Number	Linde P/N	Voltage	Current
A.A.05.0348A1	Linde Contactor	SW215-17	7915692516	48	400
A.A.05.0348G1	Copy Linde Contactor	ZJWH400A	7915692516	48	400
A.A.05.0380A1	Linde Contactor	SW215-16	7915692519	80	400
A.A.05.0380G1	Copy Linde Contactor	ZJWH400A	7915692519	80	400
A.A.05.0424A1	Linde Contactor	SW80-164L	7915692540	24	100
A.A.05.0448A1	Linde Contactor	SW80-1723P	7915692530	48	100
A.A.05.0448G1	Copy Linde Contactor	SW80P	7915692531	48	100
A.A.05.0480G1	Copy Linde Contactor	SW80P	7915692523	80	100
A.A.05.0648A1	Linde Contactor	SU280B-1268/1197	7915692535	48	400
A.A.25.0315G1	Repair Kit	SW215/ZJWH400A		/	400

Motor

◆ HELI Forklift Çekiş Motoru

XQ-5C

JXQ-8

XQ-5F

XQ-8

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.01.01.0101W	XQ-5C	Series Excited	HELI Forklift DC	
A.D.01.01.0102W	XQ-6.3-2	Series Excited	HELI Forklift DC	
A.D.01.01.0103W	XQ-6.3-5	Series Excited	HELI Forklift DC	
A.D.01.01.0104W	XQ-8	Series Excited	HELI Forklift DC	
A.D.01.01.0105W	XQ-10-1C	Series Excited	HELI Forklift DC	
A.D.01.03.0101W	JXQ-8	AC	HELI Forklift AC	
A.D.01.03.0102W	JXQ-11	AC	HELI Forklift AC	
A.D.01.03.0103W	JXQ-16.6	AC	HELI Forklift AC	
A.D.01.01.0107W	XQ-5F	Series Excited	HELI Stand Reach Forklift	
A.D.01.01.0108W	XQ-5H	Series Excited	HELI Seated Reach Forklift	
A.D.01.03.0121T	B443017G/SY04-4.5Q	AC	HELI Reach Forklift	
A.D.01.03.0805T	B451302G/SY05-11Q	AC	HELI	
A.D.01.01.0109C	XQ-5Q	Series Excited	HELI Tractor DC	
A.D.09.0104W	XQ-8-1	Series Excited	HELI Tractor DC	
A.D.09.0106C	XQ-1.5-2A	Series Excited	HELI Tractor DC	
A.D.09.0110T	B233335G/SYO3-3Q	AC	HELI Tractor AC	
A.D.09.0110W	JXQ-3S/SYO3-3Q	AC	HELI Tractor AC	
A.D.09.0113W	JXQ-3-1	AC	HELI Tractor AC	

www.arslanforklift.com

Motor

◆ HELI Forklift Lift Motoru

XQD-7.5-2C

XDQ-12

JXQD-10

XQD-13-3S

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.02.01.0101W	XQD-6.3B	Compound Excited		
A.D.02.02.0102W	XQD-7.5-C	Series Excited		
A.D.02.01.0103W	XQD-10-5	Compound Excited		
A.D.02.01.0104W	XQD-12	Compound Excited		
A.D.02.02.0105W	XQD-7.5-3S	Series Excited		
A.D.02.02.0106W	XQD-8.6-3S	Series Excited		
A.D.02.02.0107W	XQD-10-3S	Series Excited		
A.D.02.02.0108W	XQD-13-3S	Series Excited		
A.D.02.03.0101W	JXQD-10	AC		
A.D.02.03.0102W	JXQD-12	AC		
A.D.02.03.0103W	JXQD-13.5	AC		
A.D.02.02.0111W	XQD-7.5-2J	Series Excited	HELI Forklift 3 Wheels	
A.D.02.02.0112W	XQD-10-2J	Series Excited	HELI Forklift 3 Wheels	
A.D.02.02.0113W	XQD-7.5-2S	Series Excited	HELI Forklift 3 Wheels	
A.D.02.02.0114W	XQD-8.6-FQ	Series Excited	HELI Forklift 3 Wheels	
A.D.02.02.0118W	XQD-7.5H-1S	Series Excited	HELI Stand Reach Forklift	
A.D.02.02.0119W	XQD-8.6H-1S	Series Excited	HELI Seated Reach Forklift	
A.D.02.02.0120C	XQD-8.6-4S	Series Excited	Forklift Forklift 5T 80V	

www.arslanforklift.com

Motor

◆ HANGCHA Forklift Çekiş Motoru

XQ-5-1BT

XQ-5-4A4

XQ-6.3A1

HPB8.6-4

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.01.01.0201W	XQ-5-1B	Series Excited	HC Forklift DC	
A.D.01.01.0102W	XQ-6.3-2	Series Excited	HC Forklift DC	
A.D.01.01.0203B	XQ-10-1	Series Excited	HC Forklift DC	
A.D.01.02.0101W	XQ-5-1B-T	Separately Excited	HC Forklift DC	
A.D.01.02.0103W	XQ-6.3-2T	Separately Excited	HC Forklift DC	
A.D.01.02.0106B	XQ-10-1T	Separately Excited	HC Forklift DC	
A.D.01.02.0102W	XQ-5-4A4	Separately Excited	HC Forklift DC	
A.D.01.02.0104W	XQ-6.3A1	Separately Excited	HC Forklift DC	
A.D.01.02.0107W	XQ-10A	Separately Excited	HC Forklift DC	
A.D.01.02.0201W	XQ-5.2T	Separately Excited	HC Forklift DC	18 Teeth
A.D.01.02.0105W	XQ-6.3A-2	Separately Excited	HC Forklift DC	18 Teeth
A.D.01.02.0108W	XQ-10.2A-T	Separately Excited	HC Forklift DC	18 Teeth
A.D.01.03.0401H	HPQ8-4HC-A	AC	HC Forklift AC	
A.D.01.03.0402H	HPQ11-4HC-A	AC	HC Forklift AC	
A.D.01.03.0403H	HPQ15-4HC-A	AC	HC Forklift AC	
A.D.01.03.0411L	XYQ-8	AC	HC Forklift AC	
A.D.01.03.0501L	XYQ-11-B	AC	HC Forklift AC	
A.D.01.02.0110L	XQ-5H	Separately Excited	HC Reach Forklift	

www.arslanforklift.com

Motor

◆ HANGCHA Forklift Lift Motoru

XQD-10-3C

XQD-8.6-1

XQD-10-3D

XQD-8.6-3D

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.02.01.0101W	XQD-6.3B	Compound Excited	HC Forklift DC	
A.D.02.02.0102W	XQD-7.5-2C	Series Excited	HC Forklift DC	
A.D.02.02.0203B	XQD-10-3C	Series Excited	HC Forklift DC	
A.D.02.02.0204W	XQD-8.2-1	Series Excited	HC Forklift DC	
A.D.02.02.0205W	XQD-8.6-1	Series Excited	HC Forklift DC	
A.D.02.02.0212L	XQD-8.2-1H-1	Series Excited	HC Forklift DC	
A.D.02.02.0217L	XQD-8.6-1H-8	Series Excited	HC Forklift DC	
A.D.02.02.0216L	XQD-10-3H-8	Series Excited	HC Forklift DC	
A.D.02.02.0206W	XQD-8.2-3D	Series Excited	HC Forklift DC	
A.D.02.02.0207W	XQD-8.6-3D	Series Excited	HC Forklift DC	
A.D.02.02.0208W	XQD-10-3D	Series Excited	HC Forklift DC	
A.D.02.03.0201H	HPB8.6-4HC	AC	HC Forklift AC	
A.D.02.03.0202H	HPB8.6-4	AC	HC Forklift AC	
A.D.02.03.0203H	HPB10-4HC	AC	HC Forklift AC	
A.D.02.03.0213L	XYD-10-1	AC	HC Forklift AC	
A.D.02.02.0225L	XQD-7.5H	Series Excited	HC Reach Forklift	

www.arslanforklift.com

Motor

◆ Diğer Çekiş Motorları

XQ-8A

XQ-5.2T

XQ-8T

XQ-6.3-2F

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.01.01.0302B	XQ-6.3-2F	Series Excited	Tailift Forklift DC	
A.D.01.01.0303W	XQ-8A	Series Excited	Tailift Forklift DC	
A.D.01.01.0304W	XQ-10-1E	Series Excited	Tailift Forklift DC	
A.D.01.01.0313W	XQ-10-3	Series Excited	Hyundai Forklift DC	
A.D.01.01.0315W	XQ-5AH1	Series Excited	Longgong Forklift DC	
A.D.01.01.0402L	XQ-6.3-2G	Series Excited	Dalian Forklift DC	
A.D.01.01.0403L	XQ-10-1G	Series Excited	Dalian Forklift DC	
A.D.01.01.0502L	XQ-6.3-2B	Series Excited	Liugong Forklift DC	
A.D.01.02.0201W	XQ-5.2T	Separately Excited	ATF Forklift DC	
A.D.01.02.0202W	XQ-6.3A	Separately Excited	ATF Forklift DC	
A.D.01.02.0301W	XQ-5T	Separately Excited	JAC Forklift DC	
A.D.01.02.0302W	XQ-8-T	Separately Excited	JAC Forklift DC	
A.D.01.02.0303W	XQ-10-T	Separately Excited	JAC Forklift DC	
A.D.01.02.0308W	XQ-5T	Separately Excited	Noblift Forklift DC	
A.D.01.02.0306W	XQ-8T/XQT-8H	Separately Excited	Noblift Forklift DC	
A.D.01.02.0307W	XQ-10T/XQT-10-4AH	Separately Excited	Noblift Forklift DC	
A.D.01.02.0401W	XQ-5-3A1	Separately Excited	Baoli Forklift DC	
A.D.01.02.0402W	XQ-8A3	Separately Excited	Baoli Forklift DC	
A.D.01.03.0701T	B431313G/SY03-11B	AC	Goodsense Forklift AC	
A.D.01.03.0711T	B431322G/SY03-10B	AC	Tailift Forklift AC	
A.D.01.03.0807T	B451306G/SY05-11Q	AC	Youen Forklift AC	
A.D.01.03.1002T	B431323G/SY03-7.7B	AC	Dalian Forklift AC	

www.arslanforklift.com

Motor

◆ Diğer Lift Motorları

XQD-8.6

XQD-5AH

XQD-7.5-C

XQD-8.6SW

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.02.02.0301W	XQD-8.2	Series Excited	ATF Forklift DC	10 Teeth
A.D.02.02.0302W	XQD-8.6	Series Excited	ATF Forklift DC	10 Teeth
A.D.02.02.0402W	XQD-8.6-C	Series Excited	JAC Forklift DC	
A.D.02.02.0404W	XQD-13-C	Series Excited	JAC Forklift DC	
A.D.02.02.0406W	XQD-13-3D	Series Excited	JAC Forklift DC	
A.D.02.02.0502W	XQD-10-2SW	Series Excited	Jingjiang Forklift DC	
A.D.02.02.0703W	XQD-10-4D	Series Excited	TEU Forklift DC	
A.D.02.02.0803H	XQD-12-1H	Series Excited	Noblift Forklift DC	
A.D.02.02.0804L	XQD-8.6C	Series Excited	Hyundai Forklift DC	10 Teeth
A.D.02.02.1213H	XQD-8.6-1H	Series Excited	Longgong Forklift DC	
A.D.02.02.1402H	XQD-7.5-4BH	Series Excited	Xilin Forklift DC	
A.D.02.02.1602H	XQD-10-5H	Series Excited	Liugong Forklift DC	
A.D.02.03.1501T	B4328080	AC	Maximal Forklift AC	
A.D.02.03.1602T	B431323G	AC	Dalian Forklift AC	

www.arslanforklift.com

Motor

◆ Forklift Direksiyon Motor

XQD-0.9

XQD-1.35

XQD-0.8-7

XQD-0.85-1

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.03.0101B	XQD-0.55-3	Compound Excited		
A.D.03.0103W	XQD-0.75-3	Compound Excited		
A.D.03.0104W	XQD-0.8	Compound Excited		
A.D.03.0106W	XQD-1.35	Compound Excited		
A.D.03.0107Y	110SYT002	Compound Excited		
A.D.03.0108W	XQD-1.35-2	Compound Excited	HELI Tractor 10T	
A.D.03.0201W	XQD-0.8-7	Compound Excited		
A.D.03.0301W	XQD-0.8-5	Compound Excited		
A.D.03.0302L	XQD-0.9	Compound Excited	TCMC	
A.D.03.0401C	XQD-0.85-1	Compound Excited	Tailift	
A.D.03.0501L	XQD-0.8-9	Compound Excited	Xilin	
A.D.03.0115Z	B293113G/SY09-0.6Z	AC	Xilin	

www.arslanforklift.com

Motor

◆ Palet Sürüş Motoru

XQ-1.2-1A

XYJ-2.2-J

XQ-1.2T

XQ-1.5T-1

Part Number	Model Number	Excitation Mode	Forklift Model	Remark
A.D.04.01.07501	XQ-0.75-1CH1	Series Excited	Xilin	
A.D.04.01.07512	XQ-0.75-1C	Series Excited	Dalong	
A.D.04.01.09001	XQ-0.9H1	Series Excited	Xilin	
A.D.04.01.12005	XQ-1.2-3	Series Excited	MIMA	10MM Flange
A.D.04.01.12006	XQ-1.2-3	Series Excited	MIMA	8MM Flange
A.D.04.01.12009	XQ-1.5-3	Series Excited	MIMA	
A.D.04.01.12012	XQ-1.2(sealed)	Series Excited	Weishi Hai	
A.D.04.01.12034	XQ-1.2-1A	Series Excited	Dalong	
A.D.04.02.11011	XQ-1.1T-1	Separately Excited	ZoWell	
A.D.04.02.12001	XQT-1.2-3H1U	Separately Excited	Noblift	
A.D.04.02.12004	XQT-0.75-1DH1U	Separately Excited	Noblift	
A.D.04.02.12081	XQT-1.2(sealed)	Separately Excited		
A.D.04.02.12085	XQ-1.2T	Separately Excited	Dalong	
A.D.04.02.15001	XQ-1.5T-1	Separately Excited	Hangcha	
A.D.04.02.15011	XQT-1.5-9CHU	Separately Excited	Noblift	
A.D.04.03.0201B	XQY-2.2-J	AC	Liftstar	
A.D.04.03.0410A	ZPJ-1.5-4E-A	AC	EP	
A.D.04.03.0505A	XYQ-1.2FH	AC	Xilin	
A.D.04.03.0701A	XQJ-1.5BYT1	AC	MIMA	
A.D.04.04.1001	ZD11265-650W	Permanent Magnet	EP mini Pallet	

www.arslanforklift.com

Motor

◆ Lift Motorları

▶ Lift Motor Assembly (Xilin)

24V/800W
Part Number: A.D.05.02.0013

▶ Lift Motor Assembly (Liftstar)

ZD2420(24V/1.6KW)
Part Number: A.D.05.02.0040

▶ Lift Motor (Liftstar)

Liftstar460/470
Part Number: A.D.05.01.112413

▶ = Lift Motor (Liftstar)

24V/800W
Part Number: A.D.05.01.112416

▶ = Lift Motor (EP/Xilin)

ZDY211/24V-800W (right rotation)
Part Number: A.D.05.01.112410

▶ = Lift Motor (EP/Xilin/Noblift)

ZDY211S/24V-800W (left rotation)
Part Number: A.D.05.01.112411

▶ Lift Motor

M208/24V-800W
Part Number: A.D.05.01.112408

▶ Lift Motor

ZDY24800/24V-800W
Part Number: A.D.05.01.112401

▶ Lift Motor

ZD2420A/24V-2.2KW(left rotation)
Part Number: A.D.05.01.112402

▶ Lift Motor

ZD2024/24V-2.2KW(right rotation)
Part Number: A.D.05.01.1124020

▶ Lift Motor (MIMA)

semi-electric 12V
Part Number: A.D.05.01.101201

▶ Lift Motor (MIMA)

BZD-1.2G-1/24V-1.2KW
Part Number: A.D.05.01.102401

www.arslanforklift.com

Motor

◆ Lift Motorları

▶ Lift Motor (Weishi)

24V/1.3KW
Part Number: A.D.05.01.102421

▶ Lift Motor

24V/3KW (left rotation)
Part Number: A.D.05.01.112405

▶ Lift Motor Valve

Liftstar
Part Number: A.D.05.02.0063

◆ Japan Forklift Steering Motor

▶ Nichiyu Steering Motor

48V/300W
Part Number: A.D.07.0101G1

▶ Toyota Steering Motor

48V/230W
Part Number: A.D.07.0201G1

▶ Toyota Steering Motor

48V/290W
Part Number: A.D.07.0203G1

www.arslanforklift.com

▶ Toyota/Hyster/Shinko

48V/900W
Part Number: A.D.07.0205G1

▶ Toyota/Hyster/Shinko

80V/1200W
Part Number: A.D.07.0210G1

▶ TCM/Komatsu/Nichiyu

48V/400W
Part Number: A.D.07.0302G1

▶ TCM/Komatsu/Nichiyu

48V/550W
Part Number: A.D.07.0305G1

▶ TCM/Komatsu/Nichiyu

72V/550W
Part Number: A.D.07.0310G1

▶ TCM FBR15-6

48V/300W
Part Number: A.D.07.0315G1

Motor

◆ Tour Bus Çekiş Motoru

XQ-4.2-3

XQ-3-7GA

XQ-3.8

XQ-5-5H

Part Number	Model Number	Excitation Mode	Applied Brand	Remark
A.D.08.01.10483003	XQ-3-6	Series Excited	Langqing	
A.D.08.01.10484201	XQ-4.2-2A	Series Excited		18 Teeth
A.D.08.01.15482209	XQ-2.2-9H2	Series Excited	Langqing	
A.D.08.01.2009	XQ-5-7HV	Series Excited	Marshell	72V
A.D.08.01.2015	XQ-3.8-4	Series Excited	Eagle	
A.D.08.01.2040	XQ-3-1	Series Excited	Eagle	
A.D.08.02.0040	XQT-4HV	Separately Excited	Marshell	48V
A.D.08.02.0005	XQ-3-4T-2A	Separately Excited	Eagle Golf Cart	

www.arslanforklift.com

Motor Aksesuarları

◆ Motor Fırça Kutusu / Fırça Tutucular

▶ Walk Brush Carrier(bakelite)

CY/WN-5/6.3/7.5 CY-8/10

▶ Lift Brush Carrier(bakelite)

WN-XQD-12/XQD-13-3S(WN)

▶ Steering Brush Carrier(bakelite)

CY/WN/BL-XQD-0.55/XQD-0.75

▶ Walk Brush Carrier(coppery)



WN-XQ-10-1C

▶ Walk Brush Carrier(bakelite)

BL-XQ-3

▶ Walk Brush Carrier(coppery)

WN-XQ-6.3A/XQ-6.3-2T/XQ-8T

▶ Brush Carrier(bakelite)

XQ-5-4A4/XQD-10-3D/XQ-5.2T

▶ Walk Brush Carrier(bakelite)

LY-XQ-5-4A4

www.arslanforklift.com

▶ Walk Brush Carrier(coppery)

LY-XQ-5.2T/XQ-6.3A

▶ Walk Brush Carrier

BL-XQ-5

▶ Walk Brush Carrier

XQ-6.3-2/XQ-6.3-2T/XQ-8

▶ Walk Brush Carrier

BL-XQ-8-1T

▶ Brush Carrier Assembly

CY-XQ-5(inner diameter 12.9CM)

▶ Brush Carrier Assembly

CY-XQ-8(inner diameter 13.7CM)

▶ Brush Carrier Assembly

CY-XQ-10-1C(inner diameter 16.5CM)

▶ Bakelite Part

XQD-8.2/8.6KW(inner diameter 11.5CM)

Motor Aksesuarları

◆ Motor Yayları

▶ Walk Spring

XQ-6.3-2/XQ-8/XQ-10-1C

▶ Walk Spring

XQ-8/XQ-10-1C

▶ Walk Spring

XQ-5/XQ-6.3/XQ-8

▶ Walk Spring

XQ-5.2/XQ-6.3/XQ-7A/10.2A

▶ Walk/Lift Spring

XQ-5-4A4/XQD-10-3D

▶ Walk Spring

XQ-5H/XQ-5F

▶ Lift Spring

XQ-5/XQD-6.3/XQD-7.5-2

▶ Lift Spring

XQD-8.2/XQD-8.6/XQD-8.6-3D

▶ Steering Spring

XQD-12/XQD-13-3S

▶ Steering Spring

XQD-0.8-7/XQD-1.35-1

▶ Steering Spring

XQD-0.8-4A

▶ Liftstar Steering Spring

Liftstar

▶ Steering Spring

XQD-0.55-3/XQD-0.75-2/XQD-0.75-3

▶ Steering Spring

XQD-0.8/XQD-1.35

▶ HS Spring

XQ-2.2-9HR/XQ-3-6H1

▶ Brush Carrier

HC XQ-1.5T-1

www.arslanforklift.com

Motor Aksesuarları

◆ Karbon Motor Kömürleri / Fırçaları

▶ Brush

6.5*16*25 double wiring

▶ Brush

7*12.5*15.5 single wiring

▶ Brush

8*9.5*19.5 single wiring

▶ Brush

8*12*22 single wiring

▶ Brush

8*12*22 single wiring

▶ Brush

8*16*22 single wiring

▶ Brush

8x20x21(spring) single wiring

▶ Brush

8*20*22 double wiring

www.arslanforklift.com

▶ Brush

8*25*25 double wiring

▶ Brush

8*28*28 double wiring

▶ Brush



8.5*19*18 single wiring

▶ Brush

9*25*20 single wiring

▶ Brush

9*25*22(550W) single wiring

▶ Brush

9.1*19.8*26.6 double wiring

▶ Brush

10*12.5*30 single wiring

▶ Brush

10*16*20 double wiring

Motor Aksesuarları

◆ Karbon Motor Kömürleri / Fırçaları

▶ Brush

10*20*25 double wiring

▶ Brush

10*20*26 double wiring

▶ Brush

10*25*20 double wiring

▶ Brush

10*25*21 single wiring

▶ Brush

10x32x24 double wiring

▶ Brush

10*32*26 double wiring

▶ Brush

10*40*32 double wiring

▶ Brush

11*30*28 double wiring

▶ Brush

12*30*28 double wiring

▶ Brush

12*32*32 double wiring

▶ Brush

12.4*31.5*28 double wiring

▶ Brush

12.4*39.5*25 double wiring

▶ Brush

12.5*20*28 single wiring

▶ Brush

12.5*25*28 single wiring

▶ Brush

12.5*26*40 double wiring

▶ Brush

12.5*30*32 single wiring

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Motor Aksesuarları

◆ Karbon Motor Kömürleri / Fırçaları

▶ Brush

12.5*32*32 double wiring

▶ Brush

12.5*40*26 double wiring

▶ Brush

12.5*40*27 double wiring

▶ Brush

12.5*40*32 double wiring

▶ Brush

15*40*34 double wiring

▶ Brush

16*20*28 single wiring

▶ Brush

16*20*28 double wiring

▶ Brush

16*25*28 single wiring

www.arslanforklift.com

▶ Brush

16*25*28 double wiring

▶ Brush

16*25*29 single wiring

▶ Brush

16*25*30 double wiring

▶ Brush

16*25*32 single wiring

▶ Brush

16*25*32 single wiring

▶ Brush

16*25*33 single wiring

▶ Brush

16*32*32 double wiring

▶ Brush

16*40*30 double wiring

Motor Aksesuarları

◆ Enkoder

▶ SME Encoder

Part Number	Model Number	Pulse Count
A.E.05.01.0101A1	E68EC050A01	64
A.E.05.01.0101A2	E68EC080A	64
A.E.05.01.0103A1	E68EC067A01	64
A.E.05.01.0103A2	E68EC081A01	64

▶ China Encoder

Part Number	Model Number	Pulse Count
A.E.05.01.0101G1	CHS-HE06	64
A.E.05.01.0105A1	5HP421003	64
A.E.05.01.0105A2	5HP421007	64

www.arslanforklift.com

▶ SKF Encoder

Part Number	Model Number	Pulse Count
A.E.05.02.6022A1	BMB-6022E	
A.E.05.02.6202A1	BMB-6202/032S2/UA002A	32
A.E.05.02.7204A1	BMO-6204/048S2/UA008A	48
A.E.05.02.6205A1	BMB-6205/048S2/UA002A	48
A.E.05.02.6206A1	BMB-6206/064S2/UA002A	64
A.E.05.02.6209A1	BMB-6209/080S2/UB002A	80

▶ NSK Encoder

Part Number	Model Number	Pulse Count
A.E.05.02.6206A3	6206V	64
A.E.05.02.6206G1	CHS-2C6206	64

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Motor Aksesuarları

◆ Enkoder

▶ Plug–in Encoder

Part Number	Model Number	Pulse Count
A.E.05.03.0301	45MM	64
A.E.05.03.0302	35MM	64
A.E.05.03.0303	40MM	64
A.E.05.03.0304	45MM(double holes)	64

▶ Speed Motor

Part Number	Model Number	Pulse Count
A.E.05.04.0101	HS08(Yiwei)	/
A.E.05.04.0103	HS08(Eagle)	/
A.E.05.04.0105	HS03(Shifeng)	/
A.E.05.04.0107	HS02(Shifeng)	/

www.arslanforklift.com

▶ Steering Sensor(HELI Reach)

Part Number	Model Number	Pulse Count
A.E.05.04.0112	Q61F2–41311	/

▶ Xilin Motor Encoder

Part Number	Model Number	Pulse Count
A.E.05.03.0208	35MM	/

Switch Serisi

◆ Kombinasyon Switch

Combination Switch(HELI Electric Forklift)

A7S92-40191
Part Number: A.H.01.0101A

Combination Switch(HELI Electric Forklift)

A7G52-40101
Part Number: A.H.01.0103A

Combination Switch(HELI Electric Forklift)

A7J32-40111
Part Number: A.H.01.0105A

Combination Switch(HELI Electric Forklift)

AE712-40081
Part Number: A.H.01.0108A

Combination Switch(HELI Electric Forklift)

A61S2-41601Z
Part Number: A.H.01.0113A

Combination Switch(HC Electric Forklift)

FXK800-HC-G01
Part Number: A.H.01.0201A

Combination Switch(HC Electric Forklift)

JP255-700020-000
Part Number: A.H.01.0202A

Combination Switch(Longgong Electric Forklift)

JK810BB-HC
Part Number: A.H.01.0301A

Combination Switch(Noblift)

JK361
Part Number: A.H.01.1201A

Combination Switch(Noblift)

JK810JC
Part Number: A.H.01.0501A

Combination Switch(Yougao Electric Forklift)

JK803YG
Part Number: A.H.01.0701A

Combination Switch(Kaipu Forklift)

JK810KP
Part Number: A.H.01.0801A

www.arslanforklift.com

Switch Serisi

◆ Kombinasyon Switch

Combination Switch(Kaipu Forklift)

JK361KP
Part Number: A.H.01.0803A

Combination Switch(Sunward)

JK805SHZN
Part Number: A.H.01.1001A

Combination Switch(Maximal)

JK361MKS
Part Number: A.H.01.0603A

Combination Switch(Tailift Electric Forklift)

JK806AA-HC
Part Number: A.H.01.0402A

Combination Switch(direction)

JK805AA-HC
Part Number: A.H.01.0402B

Combination Switch(light)

JK804AA-HC
Part Number: A.H.01.0402C

www.arslanforklift.com

Combination Switch(normal)

JK806AA-JAC
Part Number: A.H.01.1301A

Combination Switch(direction)

JK805AA-JAC
Part Number: A.H.01.1301B

Combination Switch(light)

JK804AA-JAC
Part Number: A.H.01.1301C

Combination Switch(waterproof)

JK806AA-JAC
Part Number: A.H.01.1303A

Combination Switch(Eagle)

JK360YG
Part Number: A.H.01.0901A

Combination Switch(Yadea)

JK360YD
Part Number: A.H.01.0911A

Switch Serisi

◆ Kombinasyon Switch

Combination Switch(HELI Diesel Forklift)

H2YY2-40801
Part Number: A.H.01.5001A

Combination Switch(HELI Diesel Forklift)

A71Y2-42111Z
Part Number: A.H.01.5002A

Combination Switch(HELI Diesel Forklift)

D09JK804B
Part Number: A.H.01.5003A

Combination Switch(HELI Diesel Forklift)

G47U2-40081
Part Number: A.H.01.5004A

Combination Switch(HELI Diesel Forklift)

G15X2-40401
Part Number: A.H.01.5005A

Combination Switch(Youen)

JK804BJ/A7Y52-40601
Part Number: A.H.01.5007A

www.arslanforklift.com

Combination Switch(HELI Diesel Forklift)

G27Z2-42001/JK804C-12
Part Number: A.H.01.5009A

Combination Switch(HELI Diesel Forklift)

GY832-40501
Part Number: A.H.01.5011A

Combination Switch(HELI Diesel Forklift)

D09JK803HL
Part Number: A.H.01.5017A

Combination Switch(HC Diesel Forklift)

GR501
Part Number: A.H.01.5101A

Combination Switch(HC Diesel Forklift)

R960
Part Number: A.H.01.5102A

Combination Switch(Longgong Diesel Forklift)

JK804-3
Part Number: A.H.01.5201A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Switch Serisi

◆ Kombinasyon Switch

Combination Switch(JAC Diesel Forklift)

JK8032/JAC-026
Part Number: A.H.01.5301A

Combination Switch(Maximal Diesel Forklift)

JK803MKS
Part Number: A.H.01.5401A

Combination Switch(Maximal Diesel Forklift)

JK804MKS
Part Number: A.H.01.5402A

Combination Switch(EP Diesel Forklift)

JK803ZL
Part Number: A.H.01.5501A

Combination Switch(Goodsense Diesel Forklift)

JK805JXX
Part Number: A.H.01.5701A

Combination Switch(TCM Diesel Forklift)

FD30T3C/T6
Part Number: A.H.01.5801A1

www.arslanforklift.com

◆Direction Swtich

Direction Swtich

JK352
Part Number: A.H.02.0101

Direction Swtich

JK352(Water Proof)
Part Number: A.H.02.0103

Direction Swtich

FXK- II -06
Part Number: A.H.02.0105

Direction Swtich

FKA31-5/21
Part Number: A.H.02.0107

Direction Swtich

DZFK-48T/002
Part Number: A.H.02.0109

Direction Swtich

JK352(DL)
Part Number: A.H.02.0111

Switch Serisi

◆ Yön Switchi

Direction Swtich

15D60-50B
Part Number: A.H.02.0113

Direction Swtich

D09JK352A
Part Number: A.H.02.0115

Direction Swtich

D09JK352A(Water Proof)
Part Number: A.H.02.0117

Direction Swtich

Q64G2-40901Z(防水)
Part Number: A.H.02.0118

Direction Swtich

FXK-Ⅱ-06Q
Part Number: A.H.02.0119

Direction Swtich

FXK
Part Number: A.H.02.0121

Direction Swtich

230C2-40411
Part Number: A.H.02.0123

Contactless Direction Swtich(normal)

ETCS-FXK-402(48V)
Part Number: A.H.02.0201

Contactless Direction Swtich(waterproof)

ETCS-FXK-402A(48V)
Part Number: A.H.02.0203

Contactless Direction Swtich

ETCS-FXK401(48V)
Part Number: A.H.02.0207

Contactless Direction Swtich

ETCS-FXK-101(12V)
Part Number: A.H.02.0209

Direction Switch

Yellow
Part Number: A.H.02.0303

www.arslanforklift.com

Switch Serisi

◆ Anahtar Switch / Ateşleme Switchi

Key Switch

JK421(crossing shape key)
Part Number: A.H.05.0101

Key Switch

JK421(line style key)
Part Number: A.H.05.0103

Key Switch

JK422(crossing shape key)
Part Number: A.H.05.0102

Key Switch

JK410
Part Number: A.H.05.0105

Key Switch

JK404C-1
Part Number: A.H.05.0112

Key Switch

LAY37
Part Number: A.H.05.0111

www.arslanforklift.com

Key Switch(Diesel Forklift)

JK404C
Part Number: A.H.05.0110

Ignition Switch(Diesel Forklift)

JK411A(3 wirings)
Part Number: A.H.05.0205

Ignition Switch(Diesel Forklift)

JK411A(4 wirings)
Part Number: A.H.05.0207

Ignition Switch(Diesel Forklift)

JK406
Part Number: A.H.05.0211

Ignition Switch(Diesel Forklift)

JK406C
Part Number: A.H.05.0217

Noblift Key Switch(new)

LKS-101A
Part Number: A.H.05.0301

Switch Serisi

◆ Anahtar Switch / Ateşleme Switchi

EP Key Switch

1220-520002-AC
Part Number: A.H.05.0304

Nichiyu Key Switch(copy)

70001-33650
Part Number: A.H.05.0305

Liftstar Key Switch

2N0-2NC
Part Number: A.H.05.0401

Liftstar Key Switch(new)

JK410/530
Part Number: A.H.05.0403

Toyota Ignition Switch(copy)

57590-23340-71
Part Number: A.H.05.0405

Xilin Key Switch(new)

Part Number: A.H.05.0503

www.arslanforklift.com

◆ Lamba / Işık Switchi

Steering Light Switch(Electric Forklift 3 Wirings)

JK802B(normal)
Part Number: A.H.03.0101

Steering Light Switch(Electric Forklift 3 Wirings)

JK802B(water proof)
Part Number: A.H.03.0103

Steering Light Switch(Electric Forklift 4 wirings)

JK802A-HELI/FXK700
Part Number: A.H.03.0105

Steering Light Switch(Diesel Forklift)

JK801
Part Number: A.H.03.0109

Headlight Switch

JK107
Part Number: A.H.03.0201

Headlight Switch

JK211 (3 wirings)
Part Number: A.H.03.0203

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Switch Serisi

◆ Aydınlatma Switchi

Brake Light Switch

JK205
Part Number: A.H.03.0207

Brake Light Switch

JK231
Part Number: A.H.03.0209

Back-up Lamp Switch

JK611
Part Number: A.H.03.0213

Zero Shift Switch

JK-208A
Part Number: A.H.03.0217

Zero Shift Switch

JK-208A(normal close)
Part Number: A.H.03.0219

Lamp Switch

Komatsu 14 Series YY1001
Part Number: A.H.03.1101

www.arslanforklift.com

REMA Acil Stop Butonu

◆ RN Acil Stop Butonu

▶ RN Emergency Stop Switch

Description / Continuous Current	Model Number		
	125Amp	250Amp	300Amp
Emergency Stop Switch without Button	80225-00	80230-00	80229-00
Emergency Stop Switch with Button	80225-05	80233-00	80229-20
Emergency Stop Switch without Thread Button	80225-12		
Emergency Stop Switch without Red Button	80221-00		
Emergency Stop Switch without Thread Button	80221-07		

Switch Serisi

◆ RN Acil Stop Butonu

▶ RNA Emergency Stop Switch with Auxiliary Switch

Description	Model Number
Continuous Current	190Amp
Emergency Stop Switch without Button and Black Connector	80225-20
Emergency Stop Switch without Button and Grey Connector	80225-30
Emergency Stop Switch with Button	80226-00
Emergency Stop Switch with Thread Button	80226-50
Emergency Stop Switch with Red Button	80221-00
Emergency Stop Switch with Thread Button	80221-07

Switch Serisi

www.arslanforklift.com

◆ Albright Acil Stop Butonu

Emergency Stop Switch(Copy)

ZJK-125/ED125B-1
Part Number: A.H.04.02.0011

Emergency Stop Switch(Copy)

ZJK-250/ED250B-1
Part Number: A.H.04.02.1011

Emergency Stop Switch(Original)

ED250B-1(96V)
Part Number: A.H.04.02.1001

Emergency Stop Switch(Original)

SD150A-26B/24V(Hyster)
Part Number: A.H.04.02.2201

Emergency Stop Switch(Original)

SD200A-16/24V(Hyster)
Part Number: A.H.04.02.2301

Emergency Stop Switch(Original)

SD250A-3/24V(Hyster)
Part Number: A.H.04.02.3201

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Switch Serisi

◆ Diğer Acil Stop Butonları

HELI Emergency Stop Switch

XB2-BS542
Part Number:A.H.04.03.0103

HC Emergency Stop Switch

B2-BE102C
Part Number：A.H.04.03.0203

Liftstar Emergency Stop Switch

LA42
Part Number：A.H.04.03.0301

EP Emergency Stop Switch

ED100/48V
Part Number：A.H.04.03.0401

Noblift Emergency Stop Switch

ZDK31-250/220V
Part Number：A.H.04.02.4011

Liftstar Emergency Stop Switch

ZDK32-350
Part Number：A.H.04.03.0501

www.arslanforklift.com

◆ Mikro Switch

OMRON Microswitch

Z-15GW22-B
Part Number：A.H.06.01.0105

OMRON Microswitch

Z-15GQ22-B
Part Number：A.H.06.01.0110

Copy Microswitch

LXW5-11G2
Part Number：A.H.06.01.1105

Copy Microswitch

LXW5-11Q1(diameter 8MM)
Part Number：A.H.06.01.1110

Copy Microswitch

Z-15GQ-22B(diameter 13MM)
Part Number：A.H.06.01.1111

Copy Microswitch(TCM)

LXW6-11ZL
Part Number：A.H.06.01.1114

Switch Serisi

◆ Mikro Switch

Copy Microswitch(TCM)



LXW6-11DL
Part Number: A.H.06.01.1115

Copy Microswitch(HC Diesel Forklift)

YBLXW-5/11N1
Part Number: A.H.06.01.1116

Copy Microswitch

RZ-15GW2S-B3
Part Number: A.H.06.01.1117

OMRON Microswitch

Z-15GW2-B
Part Number: A.H.06.01.1120

Travel Switch

LX-028
Part Number: A.H.06.01.1205

Handle Microswitch(Liftstar)

SS-5
Part Number: A.H.06.01.1211

www.arslanforklift.com

Copy Limit Swtich

V-16-1C25
Part Number: A.H.06.01.2103

OMRON Microswitch

V155-1C-25
Part Number: A.H.06.01.2110

Handle Microswitch(Lift)

SS-5GL2
Part Number: A.H.06.01.2115

◆ Mikro Switch Montajlı

Hand Brake Switch Assembly

Z-15GQ22-B(normal)
Part Number: A.H.06.02.0005

Hand Brake Switch Assembly(Curtis)

Z-15GQ22-B(water proof)
Part Number: A.H.06.02.0015

Lift Swtich(EV100)

EV100
Part Number: A.H.06.03.0002

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Switch Serisi

◆ Mikro Switch Soketli

Copy Microswitch(TCM)



D0915GW2-B2/283E2-45001
Part Number: A.H.06.03.0102

Lift Switch(3 valves)

D0915GW2-B3/283E2-45101
Part Number: A.H.06.03.0103

Lift Switch(4 valves)

D0915GW2-B4/283E2-45201
Part Number: A.H.06.03.0104

Valve Control Switch(2 valves)

A61S2-40521
Part Number: A.H.06.03.0202

Valve Control Switch(3 valves)

A61S2-40531
Part Number: A.H.06.03.0203

Valve Control Switch(4 valves)

A61S2-40541
Part Number: A.H.06.03.0204

www.arslanforklift.com

◆ Diğer Switchler

Foot Horn Switch(HELI Normal)

A73J2-41502
Part Number: A.H.08.0101

Foot Horn Switch(HELI Waterproof)

A61S2-40801
Part Number: A.H.08.0102

Foot Horn Pad(HELI)

A73J2-41702
Part Number: A.H.08.1101

Lift-Fall Switch

JK932-056
Part Number: A.H.08.0109

HELI Saft Switch

V155-1C-25
Part Number: A.H.08.0113

Microswitch(JAC)

LA128 LAS
Part Number: A.H.08.0103

Switch Serisi

◆ Diğer Switchler

Lift Limit Switch(Liftstar)

LM12 3004 PB LD
Part Number: A.H.08.0117

Electronic Steering Switch(Liftstar)

SK-WW-003/KJT-J12G-ZNK
Part Number: A.H.08.0119

Lift Limit Switch(Liftstar)

TL-W5ME1
Part Number: A.H.08.0121

Lift Limit Switch(Liftstar)

RZ-15GW-B3/SS-026
Part Number: A.H.08.0123

Limit Switch(Xilin)

TZ-3112
Part Number: A.H.08.0125

Limit Switch

AZ8104/GB 14048.6-2008
Part Number: A.H.08.0127

www.arslanforklift.com

Limit Switch

LXW5-11G1/MS54
Part Number: A.H.08.0128

Microswitch

KW12-1
Part Number: A.H.08.0129

Interlock Switch(Liftstar)

Interlock Switch
Part Number: A.H.08.0201

T-MM-098 Interlock Switch(Liftstar)

RV-161-1C25
Part Number: A.H.08.0203

Rocker Switch

157
Part Number: A.H.08.3001

Rocker Switch(Forward/Backward)

3K931-052
Part Number: A.H.08.3005

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Flaş Işık / Lamba

▶HX-1101 Series LED Strobe Light

- High Brightness LED Light & Excellen Diffused Lighting Light Shell
- Magnet Installation or Screw Installation
- With Sound or Without Sound
- Color: Red, Orange, Green, Blue
- Material: Light Shell-PC, Lampholder-ABS
- Certificate: CE
- Protection Level: IP30

Color	Model	Voltage	Current	Blink Number	Weight
Red	HX-1101 LED	DC 12V	0.090A	60-80/ Per Min.	0.34KG
Orange		DC 24V	0.080A		0.34KG
Green		AC 110V	0.042A		0.51KG
Blue		AC 220V	0.021A		0.51KG

Rotation Type or Blink Type

www.arslanforklift.com

▶HX-5101 Series LED Strobe Light

- High Brightness LED Light & Excellen Diffused Lighting Light Shell
- Magnet Installation or Screw Installation
- With Sound or Without Sound
- Color: Red, Orange, Green, Blue
- Material: Light Shell-PC, Lampholder-ABS
- Certificate: CE
- Protection Level: IP30

Color	Model	Voltage	Current	Blink Number	Weight
Red	HX-5101 LED	DC 12V	0.090A	60-80/ Per Min.	0.34KG
Orange		DC 24V	0.080A		0.34KG
Green		AC 110V	0.042A		0.51KG
Blue		AC 220V	0.021A		0.51KG

Rotation Type or Blink Type

Forklift Lambaları

◆ Flaş Işık

▶HX-1081 Series LED Strobe Light

Rotation Type or Blink Type

- High Brightness LED Light & Excellen Diffused Lighting Light Shell
- Magnet Installation or Screw Installation
- With Sound or Without Sound
- Color: Red, Orange, Green, Blue
- Material: Light Shell-PC, Lampholder-ABS
- Certificate: CE
- Protection Level: IP30

Color	Model	Voltage	Current	Blink Number	Weight
Red	HX-1081 LED	DC 12V	0.090A	60-80/ Per Min.	0.34KG
Orange		DC 24V	0.080A		0.34KG
Green		AC 110V	0.042A		0.51KG
Blue		AC 220V	0.021A		0.51KG

www.arslanforklift.com

▶HX-1201 Series LED Strobe Light





Rotation Type or Blink Type

- High Brightness LED Light & Excellen Diffused Lighting Light Shell
- Magnet Installation or Screw Installation
- With Sound or Without Sound
- Color: Red, Orange, Green, Blue
- Material: Light Shell-PC, Lampholder-ABS
- Certificate: CE
- Protection Level: IP30

Color	Model	Voltage	Current	Blink Number	Weight
Red	HX-1201	DC 12V	0.090A	60-80/ Per Min.	0.34KG
Orange		DC 24V	0.080A		0.34KG
Green		AC 110V	0.042A		0.51KG
Blue		AC 220V	0.021A		0.51KG

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Flaş Işık / Led Spot / Laser Lamba

▶LED Safety Light

Part Number	Model Number	Voltage
A.J.01.4001B	SG-LW10(Blue)	10-80V
A.J.01.4001R	SG-LW10(Red)	10-80V

▶LED Safety Light(Arrowhead)

Part Number	Model Number	Voltage
A.J.01.4002B	SG-AL10(Blue)	10-80V
A.J.01.4002R	SG-AL10(Red)	10-80V

www.arslanforklift.com

▶LED Zone Strobe Light

Part Number	Model Number	Voltage
A.J.01.4003B	SG-LW18R(Blue)	10-80V
A.J.01.4003R	SG-LW18R(Red)	10-80V

▶LED Strobe Light

Part Number	Model Number	Voltage
A.J.01.2020Y	SG-SR4(Orange)	10-110V

Forklift Lambaları

◆ Tepe Lambaları / Kombinasyon Farlar

▶ Headlight(TCM/HELI)

Part Number	Model Number	Size	Voltage
A.J.02.0112A	HX-001	138*115	12V
A.J.02.0148B	HX-001	138*115	48V

▶ Headlight(HELI/Tailift/HC/Hyundai)

Part Number	Model Number	Size	Voltage
A.J.02.0212A	HX-020	105*115	12V
A.J.02.0224A	HX-020	105*115	24V

www.arslanforklift.com

▶ Combination Light(HELI/TCM)

Part Number	Model Number	Size	Voltage
A.J.02.0348A	HX-081	165*130	12V
A.J.02.0348B	HX-081	165*130	48V

▶ Headlight(TCM/Nichiyu/Komatsu)

Part Number	Model Number	Size	Voltage
A.J.02.0448A	HX-094	138*115*75	48V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Tepe Lambaları / Kombinasyon Farlar

▶Headlight(Komatsu)

Part Number	Model Number	Size	Voltage
A.J.02.0548A	HX-088	128*128*70	48V

▶Headlight(Nichiyu/Komatsu/TCM)

Part Number	Model Number	Size	Voltage
A.J.02.0648A	HX-150	100*80	48V

www.arslanforklift.com

▶LED Headlight(4 LED Bulbs)

Part Number	Model Number	Size	Voltage
A.J.02.0260A	HX-020	105*115	12-24V

▶LED Headlight(6 LED Bulbs)

Part Number	Model Number	Size	Voltage
A.J.02.0760A	HX-021	110*85	12-48V

Forklift Lambaları

◆ Tepe Lambaları / Kombinasyon Farlar

▶ Square LED Headlight(9 LED Bulbs)

Part Number	Model Number	Size	Voltage
A.J.02.0801A	HX-050	110*128*55	10-80V
A.J.02.0801B	HX-050	110*128*35	10-80V

▶ Round LED Headlight(9 LED Bulbs)

Part Number	Model Number	Size	Voltage
A.J.02.0803A	HX-052	110*128*55	10-80V
A.J.02.0803B	HX-052	110*128*35	10-80V

www.arslanforklift.com

◆ Sinyal Lambaları & Arka Lambalar

▶ Turn Light(HELI/HC/TCM)

Part Number	Model Number	Size	Voltage
A.J.03.0112A	HX-002(2 wirings)	85*85	12V
A.J.03.0112B	HX-002(3 wirings)	85*85	12V
A.J.03.0124B	HX-002(3 wirings)	85*85	24V
A.J.03.0148B	HX-002(3 wirings)	85*85	48V

▶ Turn Light(HELI/TCM/Nichiyu)

Part Number	Model Number	Size	Voltage
A.J.03.0212A	HX-021	160*50*50	12V
A.J.03.0224B	HX-021	160*50*50	24V
A.J.03.0248B	HX-021	160*50*50	48V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Sinyal Lambaları / Stop Lambaları

▶ Turn Light(Tailift/HC)

Part Number	Model Number	Size	Voltage
A.J.03.0312A	HX-071	100*50	12V

▶ Turn Light(Mitsubishi/Nichiyu)

Part Number	Model Number	Size	Voltage
A.J.03.0412A	HX-106	90*50*45	12V
A.J.03.0448A	HX-106	90*50*45	48V

www.arslanforklift.com

▶ 3 Colors Rear Lamp(HELI/Hyundai/Nichiyu/TCM)

Part Number	Model Number	Size	Voltage
A.J.03.1012A	HX-022(5 wirings)	220*54*58	12V
A.J.03.1024A	HX-022(5 wirings)	220*54*58	24V
A.J.03.1048A	HX-022(5 wirings)	220*54*58	48V
A.J.03.1048B	HX-022(6 wirings)	220*54*58	48V

▶ 3 Colors Rear Lamp(HELI)

Part Number	Model Number	Size	Voltage
A.J.03.1112A	HX-008(5 wirings)	230*60	12V
A.J.03.1124A	HX-008(5 wirings)	230*60	24V

Forklift Lambaları

◆ Sinyal Lambaları / Tepe Lambaları

▶ 3 Colors Rear Lamp(TCM/HC 30HB)

Part Number	Model Number	Size	Voltage
A.J.03.1212A	HX-003(5 wirings)	230*60	12V
A.J.03.1224A	HX-003(5 wirings)	230*60	24V

▶ 3 Colors Rear Lamp(HELI)

Part Number	Model Number	Size	Voltage
A.J.03.1312A	HX-056(5 wirings)	235*45*60	12V
A.J.03.1324A	HX-056(5 wirings)	235*45*60	24V

www.arslanforklift.com

▶ 2 Colors Rear Lamp(HELI/Hecha)

Part Number	Model Number	Size	Voltage
A.J.03.1512A	HX-007	200*52	12V
A.J.03.1524A	HX-007	200*52	24V

▶ Rear Lamp(HELI/JAC)

Part Number	Model Number	Size	Voltage
A.J.03.1612A	HX-077/D08HZHD	835*60	12V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Sinyal Lambaları / Stop Lambaları

▶ 3 Colors Rear Lamp(Mitsubishi)

Part Number	Model Number	Size	Voltage
A.J.03.1412A	HX-091	260*47*53	12V

▶ LED Turn Light(Tailift/HC)

Part Number	Model Number	Size	Voltage
A.J.03.0312B	HX-071	100*50	12-24V

www.arslanforklift.com

▶ LED 3 Colors Rear Lamp

Part Number	Model Number	Size	Voltage
A.J.03.1060A	HX-022(5 wirings)	220*54*58	12-24V

▶ LED 3 Colors Rear Lamp

Part Number	Model Number	Size	Voltage
A.J.03.1065A	HX-022(5 wirings)	220*54*58	12-24V

Forklift Lambaları

◆ Toyota Forklift Lambaları

Toyota 7FB (HX-123/48V Left)

Part Number: A.J.04.0001

Toyota 7FB (HX-123/48V Right

Part Number: A.J.04.0002

Toyota 7FB (HX-124/48V Left)

Part Number: A.J.04.0021

Toyota 7FB (HX-124/48V Right)

Part Number: A.J.04.0022

Toyota 7FD (HX-123/12V Left)

Part Number: A.J.04.0003

Toyota 7FD (HX-123/12V Right)

Part Number: A.J.04.0004

Toyota 7FD (HX-124/12V Left)

Part Number: A.J.04.0043

Toyota 7FD (HX-124/12V Right)

Part Number: A.J.04.0044

www.arslanforklift.com

Toyota 8FB (HX-126/48V Left)

Part Number: A.J.04.0005

Toyota 8FB (HX-126/48V Right

Part Number: A.J.04.0006

Toyota 8FB (HX-130/48V Left)

Part Number: A.J.04.0045

Toyota 8FB (HX-129/48V Right

Part Number: A.J.04.0046

Toyota 8FD (HX-126/12V Left)

Part Number: A.J.04.0007

Toyota 8FD (HX-126/12V Right)

Part Number: A.J.04.0008

Toyota 8FD (HX-130/12V Left)

Part Number: A.J.04.0047

Toyota 8FD (HX-129/12V Right)

Part Number: A.J.04.0048

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Forklift Lambaları

◆ Ampuller

Single Contact,Single Wiring,Flat Latch

12V/10W

Single Contact,Single Wiring,Flat Latch

12V/21W

Single Contact,Single Wiring,Flat Latch

48V/10W

Double Contact,Single Wiring,High-Low Latch

48V/40W

Double Contact,Double Wiring,High-Low Latch

12V/21W-5W

Double Contact,Double Wiring,High-Low Latch

48V/25W-10W

H3 Bulb

48V/45W

H3 Bulb

56V/55W

www.arslanforklift.com

Anderson Power Akü Soketleri

◆ Anderson Power Akü Soketleri

▶SB50

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.01.0105	SB50	600V	50A
Red	A.I.01.0110	SB50	600V	50A
Blue				

Anderson Power Akü Soketleri

◆ Anderson Power Akü Soketleri

▶SB175

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.01.0205	SB175	600V	175A
Red	A.I.01.0210	SB175	600V	175A
Blue	A.I.01.0215	SB175	600V	175A

▶SB350

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.01.0305	SB350	600V	350A
Red	A.I.01.0310	SB350	600V	350A
Blue	A.I.01.0315	SB350	600V	350A

www.arslanforklift.com

▶SBX175

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.01.1205	SBX175	600V	175A
Red	A.I.01.1210	SBX175	600V	175A
Blue	A.I.01.1215	SBX175	600V	175A

▶SBX350

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.01.1305	SBX350	600V	350A
Red	A.I.01.1310	SBX350	600V	350A
Blue	A.I.01.1315	SBX350	600V	350A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

SMH Akü Soketleri

◆ SMH Akü Soketleri

▶SMH50

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.02.0105	SMH50	600V	50A
Red	A.I.02.0110	SMH50	600V	50A
Blue	A.I.02.0115	SMH50	600V	50A

SMH Akü Soketleri

◆ SMH Akü Soketleri

▶SMH175

www.arslanforklift.com

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.02.0205	SMH175	600V	175A
Red	A.I.02.0210	SMH175	600V	175A
Blue	A.I.02.0215	SMH175	600V	175A

SMH Akü Soketleri

◆ SMH Akü Soketleri

▶SMH350

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.02.0305	SMH350	600V	350A
Red	A.I.02.0310	SMH350	600V	350A
Blue	A.I.02.0315	SMH350	600V	350A

Akü Soket Tutamağı & Kontaklar

◆ Akü Soket Tutamağı & Kontaklar

▶Handle(Grey)

175A/350A
Part Number: A.I.02.5101

▶Handle(Red)

175A/350A
Part Number: A.I.02.5105

▶Contact

SMH50
Part Number: A.I.02.6102

▶Contact

SMH175(35mm²)
Part Number: A.I.02.6105

▶Contact

SMH175(25mm²)
Part Number: A.I.02.6106

▶Contact

SMH350(50mm²)
Part Number: A.I.02.6107

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

REMA Akü Soketleri

◆ Rema Akü Soketleri

▶REMA80

Part Number	Model Number	Voltage	Current	Remark
A.I.03.0101	95199-00	150V	80A	used on forklift & battery charger
A.I.03.0114	95214-00	150V	80A	used on forklift & battery charger,with auxiliary contact
A.I.03.0111	95342-01	150V	80A	used on battery,with handle
A.I.03.0112	95309-00	150V	80A	used on battery,without handle
A.I.03.0113	95309-10	150V	80A	used on battery,with handle
A.I.03.0115	95312-01	150V	80A	used on battery,with handle and auxiliary contact

▶REMA160

Part Number	Model Number	Voltage	Current	Remark
A.I.03.0201	95039-01	150V	160A	used on forklift & battery charger,35mm2
A.I.03.0217	95044-01	150V	160A	used on forklift & battery charger, 50mm2
A.I.03.0211	95012-01	150V	160A	used on battery/35mm2, with handle
A.I.03.0213	95012-08	150V	160A	used on battery/35mm2, without handle
A.I.03.0214	95017-07	150V	160A	used on battery/35mm2, without handle
A.I.03.0218	95017-01	150V	160A	used on battery/50mm2, with handle

www.arslanforklift.com

▶REMA320

Part Number	Model Number	Voltage	Current	Remark
A.I.03.0401	95500-01	150V	320A	used on forklift & battery charger, 50mm2
A.I.03.0411	95601-05	150V	320A	used on battery,50mm2,with handle
A.I.03.0402	95515-01	/	/	auxiliary contact
A.I.03.0412	95615-05	/	/	auxiliary contact
A.I.03.0501	160/320	/	/	handle

REMA Akü Soketleri

◆ REMA AKü Soketleri

▶SR50

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.03.2001	SR50	600V	50A
Red	A.I.03.2011	SR50	600V	50A
Blue	A.I.03.2021	SR50	600V	50A

▶SR175

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.03.2301	SR175	600V	175A
Red	A.I.03.2311	SR175	600V	175A
Blue	A.I.03.2321	SR175	600V	175A

www.arslanforklift.com

▶SR350

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.03.2501	SR350	600V	350A
Red	A.I.03.2511	SR350	600V	350A
Blue	A.I.03.2521	SR350	600V	350A

▶SRE160

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.03.3201	SRE160	150V	160A
Red	A.I.03.3211	SRE160	150V	160A
Blue	A.I.03.3221	SRE160	150V	160A
Black	A.I.03.3231	SRE160	150V	160A
Green	A.I.03.3241	SRE160	150V	160A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

REMA Akü Soketleri

◆ REMA AKü Soketleri

▶SRE320

Color	Part Number	Model Number	Voltage	Current
Grey	A.I.03.3401	SRE320	150V	320A
Red	A.I.03.3411	SRE320	150V	320A
Blue	A.I.03.3421	SRE320	150V	320A
Black	A.I.03.3431	SRE320	150V	320A
Green	A.I.03.3441	SRE320	150V	320A

◆ UMA Akü Soketleri

▶UMA80

Part Number	Model Number	Voltage	Current	Remark
A.I.04.0001	UMA80	150V	80A	used on forklift & battery charger
A.I.04.0005	UMA80	150V	80A	used on battery

www.arslanforklift.com

▶UMA160

Part Number	Model Number	Voltage	Current	Remark
A.I.04.0111	UMA160	150V	160A	used on forklift & battery charger,35mm2
A.I.04.0115	UMA160	150V	160A	used on battery,35mm2
A.I.04.0116	/	/	/	auxiliary contact
A.I.04.0117	/	/	/	auxiliary contact

▶UMA320

Part Number	Model Number	Voltage	Current	Remark
A.I.04.0201	UMA320	150V	320A	used on forklift & battery charger, 50mm2
A.I.04.0205	UMA320	150V	320A	used on battery,50mm2,with handle
A.I.04.0207	UMA320	/	/	auxiliary contact
A.I.04.0209	UMA320	/	/	auxiliary contact

Akü Soketleri

◆ Diğer Akü Soketleri

Taiwa Plug(Female)

37010-10890
Part Number: A.I.06.0105

Taiwa Plug(Male)

37010-10870
Part Number: A.I.06.0205

Bakelite Connector

HX-2/175A
Part Number: A.I.07.0203

Connector(Plug)

Y-20(Grey)
Part Number: A.I.08.0101

Connector(Socket)

Y-20(Grey)
Part Number: A.I.08.0102

Connector(Plug)

Y025(Red)
Part Number: A.I.08.0103

Connector(Plug)

Y-013(Blue)
Part Number: A.I.08.0105

Connector(Plug)

Y4-40A(48V)Black
Part Number: A.I.08.0115

Connector(Socket)

Y4-40B(48V)Black
Part Number: A.I.08.0117

www.arslanforklift.com

Akü Soketleri

◆ AMP / MOLEX Konnektör



We supply American AMP & MOLEX connector.

www.arslanforklift.com

◆ Kablolar

Gaz Pedalları

◆ Gaz Pedalları

▶ EV100 Accelerator

Part Number	Model Number	Output
A.F.05.0101	HX-EV100(HL)	3.6-0V
A.F.05.0201	HX-EV100(HC)	3.6-0V
A.F.05.0301	HX-EV100(RY)	3.6-0V
A.F.05.0305	HX-EV100(RY 5 wirings)	0-5V
A.F.05.0310	HX-EV100(RY 4 wiring)	0-5V

▶ JSQD Accelerator

Part Number	Model Number	Output
A.F.03.0002	JSQD-124/001(P)	0-5V
A.F.03.0003	JSQD-124/001(F)	0-5V
A.F.03.0012	JSQD-242/001(P)	0-5V
A.F.03.0013	JSQD-242/001(F)	0-5V

www.arslanforklift.com

▶ COPP Accelerator

Part Number	Model Number	Output
A.F.04.0101	COPP16(P)	
A.F.04.0102	COPP16(F)	
A.F.04.0105	COPP13(HC/TLF)	

▶ EFP Accelerator

Part Number	Model Number	Output
A.F.01.0501	EFP-001(P)	
A.F.01.0503	EFP-001(F)	
A.F.01.0505	EFP-005	
A.F.01.0507	EFP-005(eagle)	
A.F.01.0508	EFP-005(Ivtong)	

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Gaz Pedalları

Gaz Pedalları

RJSQ Accelerator

Part Number	Model Number	Output
A.F.02.0101	RJSQ-001	0-5V
A.F.02.0103	RJSQ-001(eway)	0-5V
A.F.02.0203	RJSQ-002	3.6-0V

YF Accelerator

Part Number	Model Number	Output
A.F.06.0101	YFJS-WSK4-004	0-5V
A.F.06.0203	YFJS-WSG4-003	3.6-0V
A.F.06.0301	YFJS-WJS1-003	0-5V

www.arslanforklift.com

EFP713 Resistance Accelerator

Part Number	Model Number	Output
A.F.01.0101	FP-6(7 wirings)	
A.F.01.0201	EFP713-0502(5 wirings)	
A.F.01.0203	EFP713-0502(4 wirings)	
A.F.01.0204	EFP713-0502(4 wirings)	
A.F.01.0301	EFP713-0506(4 wirings)	

EFP712 Electronic Accelerator

Part Number	Model Number	Output
A.F.01.0103	EFP712-2410(7 wirings)	
A.F.01.0105	EFP712-2406(HELI 5 wirings)	
A.F.01.0205	EFP712-2406(HC 5 wirings)	

Gaz Pedalları

◆ Gaz Pedalları

▶ HELI Reach Forklift Accelerator

Part Number	Model Number	Output
A.F.04.0201	Q61F2-40801	0-5V
A.F.04.0205	Q69F2-40051	0-5V 3.6-0V

▶ HXJS Accelerator

Part Number	Model Number	Output
A.F.08.0102	HXJS-4805C	0-5V
A.F.08.0205	HXJS-1205	0-5V

www.arslanforklift.com

▶ Comesys Accelerator(Comesys)

Part Number	Model Number	Output
A.F.07.0101	F3-122-131	
A.F.07.0105	FZ3-532-133	
A.F.07.0203	FZ3-152-343	
A.F.07.0205	FZ3-152-341	
A.F.07.0401	FZ3-142-70	
A.F.07.1007	FZ3-133-13	
.....	.....	

▶ JCTH Accelerator

Part Number	Model Number	Output
A.F.08.1001	JCTH-3601(4 pins)	
A.F.08.1004	JCTH-3601(4 pins)	
A.F.08.1003	JCTH-3601(6 pins)	
A.F.08.1002	JCTH-8001(4 pins)	
A.F.08.1005	JCTH-8001(6 pins)	
.....	.....	

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Elektronik Throttle

Elektronik Throttle

CURTIS Throttle(24/48V)

ET-126MCU
Part Number: A.F.09.01.0101

Copy Curtis Throttle(24/48V)

ET-126
Part Number: A.F.09.01.0105

EP Throttle

ET-165
Part Number: A.F.09.01.0107

Liftstar Throttle(old)

Resistance type,2 wirings
Part Number: A.F.09.01.0201

Liftstar Throttle

AC type,3 wirings
Part Number: A.F.09.01.0203

Liftstar Throttle Assembly

AC type/4300500004
Part Number: A.F.09.01.0204

www.arslanforklift.com

Xilin Throttle

ACC01(Square Plug)
Part Number: A.F.09.01.0301

Xilin Throttle(Xilin mini pallet)

ACC009(Flat Plug)
Part Number: A.F.09.01.0302

Xilin Throttle(semi-electric)

for PG controller
Part Number: A.F.09.01.0307

MIMA Throttle

New Type
Part Number: A.F.09.01.0401

MIMA Throttle(3 wheels forklift)

DTJ07401B-H
Part Number: A.F.09.01.0111

Liftstar Board

DZ-847
Part Number: A.F.09.01.0205

Elektronik Throttle

◆ Elektronik Throttle

FREI Throttle(original)

3015F00136-00
Part Number: A.F.09.01.0502

FREI Throttle(copy)

3015F00136-00
Part Number: A.F.09.01.0501

REMA Board(copy)



Copy REMA
Part Number: A.F.09.01.0603

Noblift Throttle(mini pallet)

DTJ07410
Part Number: A.F.09.01.1100

Noblift Throttle

BD-126
Part Number: A.F.09.01.1101

Noblift Throttle

BD-190
Part Number: A.F.09.01.1102

www.arslanforklift.com

Noblift Throttle

ET-163MCU
Part Number: A.F.09.01.0108

Noblift Throttle(reach forklift)



AO1007
Part Number: A.F.09.01.0709

ET126 Throttle Handle

Handle
Part Number: A.F.09.01.0102

◆ Kumanda Kolu Montajlı

Handle

HL
Part Number: A.F.09.02.0101

Handle

HC
Part Number: A.F.09.02.0103

Handle

BYT
Part Number: A.F.09.02.0107

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

İstif Kumanda Kolları

◆ İstif Kumanda Kolları

Handle

CH-1
Part Number: A.F.09.02.0111

Handle(HELI QYD30 Tractor)

P90J2-40701
Part Number: A.F.09.02.0117

Handle(REMA)

C84663-00
Part Number: A.F.09.02.1005

Handle(copy REMA)

C84663-00
Part Number: A.F.09.02.1007

Handle(MIMA)

New Type
Part Number: A.F.09.02.1013

Handle(Xilin)

Xilin CBD15W
Part Number: A.F.09.02.1019

Handle(Xilin)

Xilin
Part Number: A.F.09.02.1020

Handle(Liftstar)

Pallet Truck (10 wirings)
Part Number: A.F.09.02.10211

Handle(Liftstar)

Stacker (11 wirings)
Part Number: A.F.09.02.1031

Handle(Liftstar)

Old type
Part Number: A.F.09.02.1033

FREI Handle

TEMO-200
Part Number: A.F.09.02.1301

Copy FREI Handle

TEMO-200(copy)
Part Number: A.F.09.02.1302

www.arslanforklift.com

İstif Kumanda Kolları

◆ İstif Kumanda Kolları

Handle(Noblift)

Silver Color
Part Number：A.F.09.02.2310

Handle(Noblift)

BD-T-103P
Part Number：A.F.09.02.2315

Handle(EP min)

1115-320000-00(no hourmeter & switch)
Part Number：A.F.09.02.2350

Handle(EP mini)

1114-340000-00-B(with hourmeter & switch)
Part Number：A.F.09.02.2355

Handle(EP pallet)

1120-340000-00(no hourmeter & switch)
Part Number：A.F.09.02.2360

Handle(EP Tractor)

QDD30
Part Number：A.F.09.02.2365

www.arslanforklift.com

Akü Göstergeleri & Zaman Saatleri

◆ Akü Göstergeleri & Zaman Saatleri

▶ CURTIS 906T

Part Number	Model Number	Voltage
A.G.01.01.0112	906T12HNDAO	12V
A.G.01.01.0124	906T24BNBA0	24V
A.G.01.01.0148	906T48HNDAO	48V
……	……	……

▶ Copy Curtis 908L

Part Number	Model Number	Voltage
A.G.01.02.0612	DLB-906L12BZ1	12V
A.G.01.02.0624	DLB-906L24BZ1	24V
A.G.01.02.0636	DLB-906L36BZ1	36V
A.G.01.02.0648	DLB-906L48BZ1	48V
A.G.01.02.0672	DLB-906L72BZ1	72V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akü Göstergeleri & Zaman Saatleri

◆ Akü Göstergeleri & Zaman Saatleri

▶ CURTIS 906D

Part Number	Model Number	Voltage
A.G.01.01.0248	906D48BNBANV	48V

▶ CURTIS 906R

Part Number	Model Number	Voltage
A.G.01.01.0324	906R24HGAAO	24V
A.G.01.01.0424	906R24BNBAO Voltage Protect	24V

www.arslanforklift.com

▶ CURTIS 803

Part Number	Model Number	Voltage
A.G.01.01.1024	803RB2436BCJ301O	24/36V
A.G.01.01.1048	803RB2448BCJ301O	24/48V
A.G.01.01.1080	803RB7280BCJ3010	72/80V

▶ Copy Curtis 808

Part Number	Model Number	Voltage
A.G.01.02.0824	DXJ-808Y24BZ1	24V
A.G.01.02.0848	DXJ-808Y48BZ1	48V
A.G.01.02.0880	DXJ-808Y80BZ1	80V

Akü Göstergeleri & Zaman Saatleri

◆ Akü Göstergeleri & Zaman Saatleri

▶ Liftstar Hourmeter

Part Number	Model Number	Voltage
A.G.01.02.1001	B902B	24V
A.G.01.02.1003	B902B(voltage protect)	24V

▶ CURTIS 840/841

Part Number	Model Number	Voltage
A.G.01.03.1005	840R015RFBA101N	24V
A.G.01.03.1011	841R48BN11001H	48V

www.arslanforklift.com

▶ GE Hourmeter

Part Number	Model Number	Voltage
A.G.01.03.0101	IC3645LXTDDT3	
A.G.01.03.0115	Copy GE	

▶ ZAPI Hourmeter

Part Number	Model Number	Voltage
A.G.01.03.0201	F04232B-MDI	12V
A.G.01.03.0215	Copy ZAPI	24-80V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akü Göstergeleri & Zaman Saatleri

◆ Akü Göstergeleri & Zaman Saatleri

▶ Danaher Hourmeter

Part Number	Model Number	Voltage
A.G.01.03.0301	OPT10-LT	24-80V
A.G.01.03.0302	OPT100-CN(copy)	24-80V

▶ SME Hourmeter

Part Number	Model Number	Voltage
A.G.01.03.0401	B00CR001B01	

www.arslanforklift.com

◆ Akü Göstergeleri & Zaman Saatleri

▶ HELI CYPD Instrument

Part Number	Model Number	Voltage
A.G.01.04.0101	CYPD-012/001(old)	48V
A.G.01.04.0103	CYPD-012/006(new)	48V
A.G.01.04.0111	CYPD(old)	48V
A.G.01.04.0113	CYPD(new)	48V
A.G.01.09.0001	CYPD(old relay board)	
A.G.01.09.0005	CYPD(new relay board)	

▶ HELI ATRB Instrument

Part Number	Model Number	Voltage
A.G.01.04.0201	H2000-B	48V
A.G.01.04.0203	ATRB-T(P)	48V
A.G.01.04.0205	ATRB-T2(F)	48V
A.G.01.04.0207	H2000-B	80V
A.G.01.04.0209	ATRB-T(P)	80V
A.G.01.04.0211	ATRB-T2(F)	80V

Akü Göstergeleri & Zaman Saatleri

◆ Göstergeler

▶ 950 Instrument

Part Number	Model Number	Voltage
A.G.01.04.0405	DK-950	
A.G.01.04.0401	950	
.....	.....	.....

▶ CURTIS enGage IV

Part Number	Model Number	Voltage
A.G.01.03.1015	17644700-5108	12-80V
A.G.01.04.0501	17644500-5089	12-80V
A.G.01.05.0401	17644500-5023	12-80V
A.G.01.05.0501	17644500-5078	12-80V
A.G.01.05.0503	17644500-5074	12-80V

www.arslanforklift.com

▶ ATF Instrument

Part Number	Model Number	Voltage
A.G.01.05.0101	CYPD-012/015	
A.G.01.05.0103	Hourmeter	
A.G.01.09.0030	Relay Board	

▶ YFYB Instrument

Part Number	Model Number	Voltage
A.G.01.05.0301	YFYB-C48/T03	48V
A.G.01.05.0305	YFYB-C80/T03	80V
A.G.01.05.0310	YFYB-G48/T03	48V
A.G.01.05.0312	YFYB-G80/T03	80V

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akü Göstergeleri & Zaman Saatleri

◆ Göstergeler

▶ CURTIS Instrument

Part Number	Model Number	Voltage
A.G.01.05.0410	3501TB-5001	

▶ ZAPI MDI CAN

Part Number	Model Number	Voltage
A.G.01.05.0517	AZ1009S	

www.arslanforklift.com

▶ ZAPI SMART DISPLAY

Part Number	Model Number	Voltage
A.G.01.04.0601	SMART DISPLAY	36/48V
A.G.01.05.0513	SMART DISPLAY	80V

▶ HXYB-B Instrument

Part Number	Model Number	Voltage
A.G.01.07.B4801	HXYB-B4800ZH	48V
A.G.01.07.B7200	HXYB-B7200BZ	72V
A.G.01.07.B7201	HXYB-B7200ZH	72V

Akü Göstergeleri & Zaman Saatleri

◆ Dizel Forklift Göstergeleri & Zaman Saatleri

HELI H2000(Manual Transmission)

Part Number：A.G.02.01.0101

HELI H2000(Automatic Transmission

Part Number：A.G.02.01.0103

HELI ZB908

Part Number：A.G.02.01.0105

HELI ZB909

Part Number：A.G.02.01.0107

HELI CYPC-12-05

Part Number：A.G.02.01.0110

HELI CPC-01(H2009)

Part Number：A.G.02.01.0109

www.arslanforklift.com

CPCQ-12/05

Part Number：A.G.02.01.0119

Hangcha 12V

Part Number：A.G.02.01.0151

TCMC Hourmeter

Part Number：A.G.02.01.0301

Dalian H2002

Part Number：A.G.02.01.0233

HELI Hourmeter

Part Number：A.G.02.01.0121

Fuel Gauge 12V

Part Number：A.G.02.03.0650

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akü Şarj Cihazı & Şarj Ekipmanları

◆ Akü Şarj Cihazı (Tek Faz)

Feature:

- ◇ Closed–loop control and automatic check during charging, in order to keep battery in good state.
- ◇ After open, the charger automatic starts and work according to applied charging curve.
- ◇ Small size, user–friendly, simple maintenance, charging time 8–12 hours.

Technical Parameters:

Model Number	Input Voltage	Power	Size	Battery Capacity	Weight
GCAZX–24V/30A	Single Phase220V	1.2KVA	360*300*350mm	210–250AH	24KG
GCAZX–24V/40A	Single Phase 220V	1.6KVA	360*300*350mm	280–350AH	29KG
GCAZX–24V/50A	Single Phase 220V	2.0KVA	460*410*500mm	350–390AH	39KG
GCAZX–24V/60A	Single Phase220V	2.7KVA	460*410*500mm	400–440AH	50KG
GCAZX–48V/30A	Single Phase220V	1.8KVA	460*410*500mm	210–250AH	45KG
GCAZX–48V/35A	Single Phase 220V	2.1KVA	460*410*500mm	280–350AH	47KG
GCAZX–48V/40A	Single Phase 220V	2.4KVA	460*410*500mm	280–350AH	48KG

www.arslanforklift.com

Working Condition:

- ◇ Not more than 1200m altitude
- ◇ Woking temperature: –10℃~40℃
- ◇ Not more than 90% air humidity
- ◇ Make sure no combustible objects around charger and charger wirings.

Akü Şarj Cihazı & Şarj Ekipmanları

◆ Akü Şarj Cihazı (3 Faz)

Feature:

- ◇ Closed-loop control and automatic check during charging, in order to keep battery in good state.
- ◇ After open, the charger automatic starts and work according to applied charging curve.
- ◇ Small size, user-friendly, simple maintenance, charging time 8-12 hours.

Technical Parameters:

Model Number	Input Voltage	Power	Size	Battery Capacity	Weight
GCAZX-48V/40A	3 Phase 380V	3.0KVA	460*410*500mm	280-350AH	45KG
GCAZX-48V/45A	3 Phase 380V	3.4KVA	460*410*500mm	350-390AH	50KG
GCAZX-48V/50A	3 Phase 380V	3.8KVA	460*410*500mm	350-390AH	50KG
GCAZX-48V/60A	3 Phase 380V	4.5KVA	460*410*500mm	400-440AH	55KG
GCAZX-48V/70A	3 Phase 380V	5.5KVA	460*410*500mm	480-550AH	65KG
GCAZX-48V/80A	3 Phase 380V	6.0KVA	540*490*600mm	550-630AH	65KG
GCAZX-48V/100A	3 Phase 380V	7.5KVA	540*490*600mm	630-700AH	75KG
GCAZX-72V/60A	3 Phase 380V	6.8KVA	460*410*500mm	400-440AH	68KG
GCAZX-72V/70A	3 Phase 380V	7.9KVA	540*490*600mm	480-550AH	78KG
GCAZX-72V/80A	3 Phase 380V	9.0KVA	540*490*600mm	550-630AH	85KG
GCAZX-80V/60A	3 Phase 380V	7.5KVA	460*410*500mm	400-440AH	70KG
GCAZX-80V/70A	3 Phase 380V	8.8KVA	540*490*600mm	480-550AH	80KG
GCAZX-80V/80A	3 Phase 380V	10.0KVA	540*490*600mm	550-630AH	85KG
GCAZX-80V/100A	3 Phase 380V	12.5KVA	540*490*600mm	630-700AH	90KG

www.arslanforklift.com

Working Condition:

- ◇ Not more than 1200m altitude
- ◇ Woking temperature: -10℃~40℃
- ◇ Not more than 90% air humidity
- ◇ Make sure no combustible objects around charger and charger wirings.

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akü Şarj Cihazı & Şarj Ekipmanları

◆ Akü Şarj Ekipmanları

DQ35A

Part Number：A.M.02.01130

HDS65A–400V

Part Number：A.M.02.01151

HDS100A–400V

Part Number：A.M.02.01152

Charger Board (24V)

Part Number：A.M.02.02024

Charger Board (48V)

Part Number：A.M.02.02148

Charger Board (80V)

Part Number：A.M.02.02180

www.arslanforklift.com

Charger Board (new)

Part Number：A.M.02.12148

Fuse F100A

Part Number：A.M.02.03100

Fuse F150A

Part Number：A.M.02.03150

Binding Post

Part Number：A.M.02.0401

Button

Part Number：A.M.02.0501

A9D–30–01/380V

Part Number：A.M.02.40220

Akü Şarj Cihazı & Şarj Ekipmanları

◆ Delong Yüksek Frekans Akü Şarj Cihazları

Part Number	Input Voltage	Battery Voltage	Output Current	Mark
A.M.10.2425J	Single Phase 200~240VAC	24V	25A	Lead-acid Battery
A.M.10.2425M	Single Phase 200~240VAC	24V	25A	Gel Sealed Battery
A.M.10.2430J	Single Phase 200~240VAC	24V	30A	Lead-acid Battery
A.M.10.2430M	Single Phase 200~240VAC	24V	30A	Gel Sealed Battery
A.M.10.2440J	Single Phase 200~240VAC	24V	40A	Lead-acid Battery
A.M.10.2440M	Single Phase 200~240VAC	24V	40A	Gel Sealed Battery
A.M.10.3630J	Single Phase 200~240VAC	36V	30A	Lead-acid Battery
A.M.10.3630M	Single Phase 200~240VAC	36V	30A	Gel Sealed Battery
A.M.10.4820J	Single Phase 200~240VAC	48V	20A	Lead-acid Battery
A.M.10.4820M	Single Phase 200~240VAC	48V	20A	Gel Sealed Battery
A.M.10.4825J	Single Phase 200~240VAC	48V	25A	Lead-acid Battery
A.M.10.4825M	Single Phase 200~240VAC	48V	25A	Gel Sealed Battery
A.M.10.4830J	Single Phase 200~240VAC	48V	30A	Lead-acid Battery
A.M.10.4830M	Single Phase 200~240VAC	48V	30A	Gel Sealed Battery
A.M.10.7225J	Single Phase 200~240VAC	72V	25A	Lead-acid Battery
A.M.10.7225M	Single Phase 200~240VAC	72V	25A	Gel Sealed Battery

www.arslanforklift.com

Feature:

- Closed-loop control and automatic check during charging, in order to keep battery in good state.
- After open, the charger automatic starts and work according to applied charging curve.
- Small size, user-friendly, simple maintenance, charging time 8-12 hours.

Working Condition:

- Not more than 1200m altitude
- Woking temperature: -10℃~40℃
- Not more than 90% air humidity
- Make sure no combustible objects around charger and charger wirings.

Akü Şarj Cihazı & Şarj Ekipmanları

◆ Diğer Akü Şarj Cihazları

Liftstar Battery Charger 24V/50A

Part Number: A.M.04.0001

Liftstar Battery Charger 24V/6A

Part Number: A.M.04.0008

Noblift Battery Charger 24V/8A

Part Number: A.M.05.240801

EP Battery Charger 24V/10A

Part Number: A.M.05.241001

EP Battery Charger 24V/10A

Part Number: A.M.05.241002

Xilin Battery Charger 24V/10A

Part Number: A.M.05.241008

www.arslanforklift.com

Battery Charger 12V/15A

Part Number: A.M.06.1215J

Battery Charger 12V/20A

Part Number: A.M.06.1220J

Battery Charger 24V/10A

Part Number: A.M.06.2410J

Battery Charger 24V/15A

Part Number: A.M.06.2415J

Battery Charger 24V/20A

Part Number: A.M.06.2420J

Battery Charger 24V/30A

Part Number: A.M.06.2430J

Diğer Elektronik Parçalar

◆ DC - DC Converter

B Model DC (48V-12V)

Part Number: A.P.04.01.4113

B Model DC (72V-12V)

Part Number: A.P.04.01.7113

C Model DC (48V-12V)

Part Number: A.P.04.03.4113

C Model DC (72V-12V)

Part Number: A.P.04.03.7113

HELI DC (48V-12V)

Part Number: A.P.04.11.014812

DCDC-080-126B

Part Number: A.P.04.11.018012

DCDC-048/123(F)

Part Number: A.P.04.11.214813

SEVCON 622/11101 H

Part Number: A.P.04.11.038012

◆ Sensörler

Lift Sensor(water proof)

Part Number;A.O.01.0001

Liftstar Angle Sensor

Part Number: A.O.01.0011

Liftstar Sensor Gear

Part Number: A.O.01.00111

Liftstar Steering Encoder

Part Number: A.O.01.0012

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Diğer Elektronik Parçalar

◆ Sensörler

HC Speed Sensor

Part Number: A.O.01.1005

Toyota 7FB Angle Sensor

Part Number: A.O.02.0011

Nichiyu Steering Sensor

Part Number: A.O.03.0002

Nichiyu Current Sensor

Part Number: A.O.03.0011

Nichiyu Speed Sensor

Part Number: A.O.03.0021

TCM FB-7 Speed Sensor

Part Number: A.O.05.0002

TCM Steering Sensor

Part Number: A.O.05.0021

TCM Relay G7L-2A-T

Part Number: A.O.05.9002

www.arslanforklift.com

◆ Kontrol Kutusu / Sigorta Kutusu / Sigortalar

HELI Control Box

Part Number: A.P.01.0001

HELI Control Box DQH-012-HL

Part Number: A.P.01.0412

HELI BX2081D

Part Number: A.P.02.0101

HELI BX2081D(water proof)

Part Number: A.P.02.0103

Diğer Elektronik Parçalar

◆ Kontrol Kutusu / Sigorta Kutusu / Sigortalar

HELI P90H2-40311

Part Number: A.P.02.0105

Fuse Box BX2081X

Part Number: A.P.02.0104

Fuse Box P91A2-40511

Part Number: A.P.02.0113

HC232Z2-42131(6 wirings)

Part Number: A.P.02.0201

HC216G2-40801A(8 wirings)

Part Number: A.P.02.0205

HC235C2-40301(10 wirings)

Part Number: A.P.02.0203

Fuse Box BX2051X

Part Number: A.P.02.0301

Baoli BX2083XA

Part Number: A.P.02.0501

Fuse(50A~500A)

Part Number: A.P.03.01

Fuse(50A~500A)

Part Number: A.P.03.02

Fuse 125A

Part Number: A.P.03.02.3125

Fuse 150A

Part Number: A.P.03.02.2150

Fuse(10A~30A)



Part Number: A.P.03.03

Fuse Holder RT14-20

Part Number: A.P.03.03.1021

White Fuse Holder

Part Number: A.P.03.02.5001

Fusible Wire(12V~24V)

Part Number: A.P.03.04

www.arslanforklift.com

Diğer Elektronik Parçalar

◆ Diğer Parçalar / Fanlar

Glow Plug Relay(12V/24V)

Part Number：A.P.08

Time Actuator(12V/24V)

Part Number：A.P.09

Regulator(12V/24V)

Part Number：A.P.11

Flasher(12V~48V)

Part Number：A.P.07

Buzzer(12V~48V)

Part Number：A.P.10.01

Voice Buzzer (12V~48V)

Part Number：A.P.10.02

Horn (12V~48V)

Part Number：A.P.12

HELI Horn Filter

Part Number：A.P.05

www.arslanforklift.com

HELI Delay Box

Part Number：A.P.13.0001

HELI F1 Delay Box

Part Number：A.P.13.0015

HELI Foot Brake Control Box

Part Number：A.P.06

Fan 60*60 (12~24V)

Part Number：A.P.14.060

Fan 80*80 (12~24V)

Part Number：A.P.14.080

Fan 120*120 (12~48V)

Part Number：A.P.14.120

Heat Conductive Silicone Grease

Part Number：A.Z.0001

Shunt 75mv300A

Part Number：A.Z.0201

Yürüyüş Ekipmanları

◆ Yürüyüş Tekeri Montajlı / Redüktör

Installation	Motor Excitation	Motor Power	Voltage	Current
Horizontal Type	Series Excited Separately Excited AC	0.75~1.2KW 0.75~1.2KW 1.2KW	24V 24V 24V	46A~76A 46A~62A 81A
Vertical Type	Series Excited Separately Excited AC AC	1.2~1.5KW 1.2~2.2KW 1.2KW 1.1KW	24V 24V 24V 24V	68A~76A 68A~118A 76A 74A

www.arslanforklift.com

Elektrik Fren

◆ Elektrik Fren

▶ Electric Brake

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.0101R	G247-REB0908(14T)ZE-R	24V	8N.m	14mm
B.H.20.1101C	Z062-C08(24V14)824V	24V	8N.m	14mm

▶ Electric Brake

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.0105R	G247-REB0908(15T)ZE-R	24V	8N.m	15mm
B.H.20.1105C	Z054-C08(24V15)8	24V	8N.m	15mm

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Elektrik Fren

◆ Elektrik Fren

▶ Electric Brake

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.0110R	G072-REB0510(20)Z-R	24V	16N.m	20mm
B.H.20.1110C	Z068-Z10(24V20)16	24V	16N.m	20mm

▶ Electric Brake (EP mini Pallet)

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.1120C	CDC-C06(24V15)6	24V	6N.m	15mm

▶ Electric Brake (Xilin)

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.1125C	Z068-C08(24V15)8	24V	8N.m	15mm

▶ Electric Brake (Liftstar)

Part Number	Model Number	Voltage	Torque	Inner Diameter
B.H.20.6130L	Z067-C10(24V20)16	24V	16N.m	20mm
B.H.20.6130LB	Brake Encoder	/	/	/

www.arslanforklift.com

PU Yürüyüş Tekerleri

◆PU Yürüyüş Tekerleri

Photo			Used on	Photo			Used on
	210	70/83	EP		254	88	EP
	248	75	Liftstar BT		252	67	Liftstar
	215	75/90	MIMA		343	108	MIMA
	220	70	Noblift		250	80	Noblift Ouneng
	250	100/140	Xilin		250	70/90	Xilin

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

PU Yürüyüş Tekerleri

◆ PU Yürüyüş Tekerleri

Photo			Used on	Photo			Used on
	254	95	EP		230	75/82	Hangcha EP Noblift Zowelll Jungheinrich
	252	67	Liftstar		250	85	Hangcha
	343	114	Hangcha		343	135	Hangcha
	252	88	Noblift		252	88	Noblift
	250	80/92	DC Xilin		250	80/92	AC Xilin

www.arslanforklift.com

PU Yürüyüş Tekerleri

◆PU Yürüyüş Tekerleri

Photo			Used on	Photo			Used on
	230	90	Linde 4 Bolts		330	145	Nichiyu TCM Shinko
	230	90	Linde 5 Bolts		330	145	Toyota 6FBR10–18 7FBR10–18
	254	102	Linde T20		330	145	TCM
	310	120	BT 7 Bolts		330	145	Hyster
	310	120	BT 5 Bolts		343	114	Jungheinrich
	330	135	Linde R14		343	135	Linde R14S,R16S

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

PU Denge Tekerleri

◆ Pu Denge Tekerleri

Photo				Used on
	100	40	47	Noblift
	115	55	52	Liftstar EP
	138	60/68	52	Liftstar
	150	54/58	47	Noblift
	100	40	52	Hangcha
	125	50	52	Hangcha
	149	49/56	47	Liftstar
	178	73	52/62	Hangcha

Photo				Used on
	100	40	35	MIMA Liftstar Linde Still
	125	60	47	Noblift Jungheinrich Hangcha Linde
	140	55	52	Hangcha
	150	60/65	47	Xilin
	102	64	52	EP
	127	57/60	40	Xilin
	150	50	47	MIMA Hyster
	130	55/60	52	Hangcha EP

www.arslanforklift.com

PU Denge Tekerleri

◆PU Denge Tekerleri

Photo				Used on
	100	40	32	Linde
	125	40/45	35	Linde T20
	150	50/60	55	Linde L10,L12
	125	50	52	Hyster
	125	60	55	Linde
	140	50	47	Linde L16
	140	50/60	55	Linde L16
	140	54/60	47	Jungheinrich

Photo				Used on
	150	80	66/73	Toyota 7FBR15
	178	73	52/62	Nichiyu
	178	73	72	Nichiyu TCM
	178	73	72	Hyundai
	178	73	72	Toyota 6FBR
	178	73	52/62	Hyster Shinko
	204	76	52/62	Nichiyu
	204	76	62	Toyota 5FBR20-30 6FBR20-30 7FBR20-30

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

PU Yük Tekerleri

◆ PU Yük Tekerleri

Photo				Used on	Photo				Used on
	73	98	47	Liftstar		74	93	47	Noblift
	80	70	47	HELI xilin Noblift		80	80	52	Liftstar EP
	80	120	52	Liftstar HELI EP		82	165	52	EP
	84	70	47	Noblift		84	80	55	Liftstar
	80	58	52	Liftstar		84	70	52	Liftstar
	80	93	47	HELI Noblift		85	48	47	EP

www.arslanforklift.com

PU Yük Tekerleri

◆PU Yük Tekerleri

Photo				Used on	Photo				Used on
	85	70	52	HELI Hangcha EP		85	70	47	Hangcha Noblift Linde Hyster
	85	85	52	Hangcha		85	110	55	Hangcha Jungheinrich
	160	73	72	Liftstar		250	120	72	Hangcha
	285	110	68	Hangcha		343	108	72	Hangcha
	85	70	55	Hangcha		267	114	98	MIMA
	85	115	52	EP		80	60	47	HELI EP

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

PU Yük Tekerleri

◆ PU Yük Tekerleri

Photo				Used on	Photo				Used on
	85	60	55	Linde L10,L12		85	90	55	Hyster Jungheinrich
	85	75	47	Toyota BT		85	98	52	Hyster
	85	80	55	Linde T20		85	105	55	Linde
	85	80	47	Linde		127	98	62	Hyster
	85	80	55	Linde		130	73	62	Hyster
	85	85	55	Jungheinrich		204	127	65/69	Hyster

www.arslanforklift.com

PU Yük Tekerleri

◆PU Yük Tekerleri

Photo				Used on
	254	80	170	Linde
	254	100	90	Hyundai Shinko
	254	102	169	Hyster
	254	114/120	180	Nichiyu
	254	120	190	Toyota 6FBR15
	254	120	190	Toyota 7FBR15 –18

Photo				Used on
	254	120	169	Daewoo
	254	120	158	Toyota 7FBR10
	267	114	110	Hyundai
	285	100	72	Linde R14,R16
	285	100	63	Jungheinrich
	285	100	68	Jungheinrich

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

PU Transpalet Tekerleri

◆ PU Transpalet Tekerleri

Photo			
	128	40	47
	150	50	47
	160	50	47
	180	50	47
	200	50	47
	70	60	47
	74	55	47
	74	70	47
	80	55	47
	80	60	47

Photo			
	80	70	47
	80	90	47
	70	60	47
	74	70	47
	80	60	47
	80	70	47
	80	93	47
	160	50	47
	180	50	47
	200	50	47

www.arslanforklift.com

PU Tekerlek Ekipmanları

◆ PU Tekerlek Ekipmanları

EP Pallet 130*55

Part Number: B.G.01.3040

Xilin Pallet 80*70

Part Number: B.G.01.1342

Noblift Pallet 74*70

Part Number: B.G.01.1248

EP Pallet 80*60

Part Number: B.G.01.3042

Liftstar Pallet 80*80

Part Number: B.G.01.1006

Liftstar

Part Number: B.G.01.1015

Liftstar

Part Number: B.G.01.1020

Liftstar

Part Number: B.G.01.1024

www.arslanforklift.com

Liftstar

Part Number: B.G.01.1025

6006 Bearing

Part Number: B.G.99.6006

6202 Bearing

Part Number: B.G.99.6202

6204 Bearing

Part Number: B.G.99.6204

6205 Bearing

Part Number: B.G.99.6205

6206 Bearing

Part Number: B.G.99.6206

6208 Bearing

Part Number: B.G.99.6208

6304 Bearing

Part Number: B.G.99.6304

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Havalı Piston

◆ Havalı Piston

Handle Gas Spring (MIMA 350N)

Part Number: B.I.01.0001

Handle Gas Spring (Noblift 500N)

Part Number: B.I.01.0005

Handle Gas Spring (Noblift 400N)

Part Number: B.I.01.0006

Handle Gas Spring (HC 600N)

Part Number: B.I.01.0021

Handle Gas Spring (HELI 350N)

Part Number: B.I.01.0011

Handle Gas Spring (Liftstar/HC 370N)

Part Number: B.I.01.0041

Handle Gas Spring (Liftstar 350N)

Part Number: B.I.01.0042

Handle Gas Spring (400N)

Part Number: B.I.01.0058

Handle Gas Spring (EP 430N)

Part Number: B.I.01.0035

Handle Gas Spring (EP 750N)

Part Number: B.I.01.0036

Handle Gas Spring (Xilin 250N)



Part Number: B.I.01.0061

Handle Gas Spring (Xilin 420N)

Part Number: B.I.01.0063

www.arslanforklift.com

Handle Gas Spring (Xilin 420N)

Part Number: B.I.01.0065

Handle Gas Spring (Hyster 800N)

Part Number: B.I.01.1001

Handle Gas Spring (Jungheinrich 350N)

Part Number: B.I.01.1065

Foot Pedal Gas Spring (MIMA 800N)

Part Number: B.I.01.0003

Foot Pedal Gas Spring (Noblift 700N)

Part Number: B.I.01.0007

Foot Pedal Gas Spring (EP 600N)

Part Number: B.I.01.0038

Foot Pedal Gas Spring (Liftstar 680N)

Part Number: B.I.01.0043

Foot Pedal Gas Spring (Liftstar D716-C)

Part Number: B.I.01.0044

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.03.01484001
Applied Forklift	HELI
Model Number	48V/400AH
Battery Box Size	970*600*465
Connector Model	175A

Part Number	A.K.07.03.01485501
Applied Forklift	HELI
Model Number	48V/550AH
Battery Box Size	970*715*500
Connector Model	175A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.01486001
Applied Forklift	HELI
Model Number	48V/600AH
Battery Box Size	1030*500*792
Connector Model	350A

Part Number	A.K.07.03.01487001
Applied Forklift	HELI
Model Number	48V/700AH
Battery Box Size	1030*500*792
Connector Model	350A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.05.01804801
Applied Forklift	HELI
Model Number	80V/480AH
Battery Box Size	1028*711*784
Connector Model	320A

Part Number	A.K.07.05.01805001
Applied Forklift	HELI
Model Number	80V/500AH
Battery Box Size	1145*585*803
Connector Model	350A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.02484501
Applied Forklift	Hangcha
Model Number	48V/450AH
Battery Box Size	980*680*485
Connector Model	160A

Part Number	A.K.07.03.02486301
Applied Forklift	Hangcha
Model Number	48V/630AH
Battery Box Size	845 * 1064 * 465
Connector Model	320A

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.03.02486302
Applied Forklift	Hangcha
Model Number	48V/630AH
Battery Box Size	1028*570*780
Connector Model	320A

Part Number	A.K.07.05.02804801
Applied Forklift	Hangcha
Model Number	48V630AH
Battery Box Size	1075*995*495
Connector Model	320A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.05.02805003
Applied Forklift	Hangcha
Model Number	80V/500AH
Battery Box Size	1028*710*780
Connector Model	320A

Part Number	A.K.07.01.03242102
Applied Forklift	Liftstar
Model Number	24V/210AH
Battery Box Size	790*210*576
Connector Model	175A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.01.03242702
Applied Forklift	Liftstar
Model Number	24V/270AH
Battery Box Size	790*210*576
Connector Model	175A

Part Number	A.K.07.01.03242802
Applied Forklift	Liftstar
Model Number	24V/280AH
Battery Box Size	648*248*548
Connector Model	175A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.01.05242105
Applied Forklift	Xilin
Model Number	24V/210AH
Battery Box Size	745*170*534
Connector Model	Red175A

Part Number	A.K.07.01.05242401
Applied Forklift	Xilin
Model Number	24V/240AH
Battery Box Size	654*254*478
Connector Model	Red175A

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.01.05242402
Applied Forklift	Xilin
Model Number	24V/240AH
Battery Box Size	650*250*500
Connector Model	Red 175A

Part Number	A.K.07.03.16484508
Applied Forklift	Xilin
Model Number	48V/450AH
Battery Box Size	980*660*450
Connector Model	160A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.05.03805001
Applied Forklift	Tailift
Model Number	80V/500AH
Battery Box Size	1124*610*800
Connector Model	350A

Part Number	A.K.07.01.06242105
Applied Forklift	Noblift
Model Number	24V/210AH
Battery Box Size	790*210*460
Connector Model	80A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.03.03485001
Applied Forklift	Tailift
Model Number	48V/500AH
Battery Box Size	965*430*760
Connector Model	350A

Part Number	A.K.07.03.03486001
Applied Forklift	Tailift
Model Number	48V/600AH
Battery Box Size	975*495*800
Connector Model	350A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.28484005
Applied Forklift	Noblift
Model Number	48V/400AH
Battery Box Size	970*650*440
Connector Model	160A

Part Number	A.K.07.03.28486008
Applied Forklift	Noblift
Model Number	48V/600AH
Battery Box Size	975*466*780
Connector Model	320A

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.01.08242101
Applied Forklift	MIMA
Model Number	24V/210AH
Battery Box Size	645*196*560
Connector Model	175A

Part Number	A.K.07.01.30242301
Applied Forklift	Linde
Model Number	24V/230AH
Battery Box Size	621*206*625
Connector Model	80A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.30485601
Applied Forklift	Linde
Model Number	48V/560AH
Battery Box Size	832*523*782
Connector Model	160A

Part Number	A.K.07.03.30485755
Applied Forklift	Linde
Model Number	48V/575AH
Battery Box Size	827*627*625
Connector Model	160A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.03.33482805
Applied Forklift	Nichiyu
Model Number	48V/280AH
Battery Box Size	956*375*550
Connector Model	175A

Part Number	A.K.07.03.36484005
Applied Forklift	Toyota
Model Number	48V/400AH
Battery Box Size	815*740*479
Connector Model	175A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.36484804
Applied Forklift	Toyota
Model Number	48V/480AH
Battery Box Size	900*810*479
Connector Model	350A

Part Number	A.K.07.03.40484001
Applied Forklift	TCM
Model Number	48V/400AH
Battery Box Size	980*600*495
Connector Model	175A

Traksiyoner Aküler

◆ Traksiyoner Aküler

▶ Traction Battery

Part Number	A.K.07.03.40484802
Applied Forklift	TCM
Model Number	48V/480AH
Battery Box Size	1028*778*495
Connector Model	350A

Part Number	A.K.07.03.40485601
Applied Forklift	TCM
Model Number	48V/560AH
Battery Box Size	1028*778*495
Connector Model	350A

www.arslanforklift.com

▶ Traction Battery

Part Number	A.K.07.03.04487101
Applied Forklift	Hyundai
Model Number	48V/715AH
Battery Box Size	1066*796*537
Connector Model	350A

Part Number	A.K.07.05.04805202
Applied Forklift	Hyundai
Model Number	80V/520AH
Battery Box Size	1066*990*520
Connector Model	350A

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Motor Tamir Kitleri

◆ Motor Tamir Kitleri

▶ Engine Repair Kit

Part Number	Name	Engine Model
B.A.01.02.0021	Piston & Liner Assembly	C240 3 Ring
B.A.01.02.0025	Engine Repair Kit	C240
B.A.01.02.0026	Crankshaft Bearing	C240STD/+25/+50/+75
B.A.01.02.0027	Connecting Rod Bearing	C240STD/+25/+50/+75
B.A.01.02.0047	Thrust Washer	C240STD
B.A.02.02.0001	Valve	C240
B.A.02.02.0005	Valve Ring	C240
B.A.02.02.0004	Valve Guide	C240
B.A.01.02.0041	Crankshaft	C240

Part Number	Name	Engine Model
B.A.01.08.0002	Piston	K25/1.5MM/1.2MM Ring
B.A.01.07.0001	Liner	K25
B.A.01.08.0003	Piston Ring	K25/1.5MM/1.2MM Ring
B.A.01.07.0009	Engine Repair Kit	K25
B.A.01.05.0005	Crankshaft Bearing	K25STD/+25/+50/+75
B.A.01.05.0007	Connecting Rod Bearing	K25STD/+25/+50/+75
B.A.02.08.0001	Valve	K25
B.A.02.08.0009	Valve Ring	K25
B.A.02.08.0003	Valve Guide	K25
B.A.01.08.0011	Crankshaft	K25

Part Number	Name	Engine Model
B.A.01.40.0002	Liner	Jiang Ling493
B.A.01.40.00041	Piston	Jiang Ling493
B.A.01.40.00051	Piston Ring	Jiang Ling493
B.A.01.40.0001	Engine Repair Kit	Jiang Ling493
B.A.01.40.0008	Crankshaft Bearing	Jiang Ling493STD/+25/+50/+75
B.A.01.40.0003	Connecting Rod Bearing	Jiang Ling493STD/+25/+50/+75
B.A.01.40.0009	Thrust Washer	Jiang Ling493STD
B.A.02.22.0003	Valve	Jiang Ling493
B.A.02.22.0005	Valve Ring	Jiang Ling493
B.A.02.22.0007	Valve Guide	Jiang Ling493
B.A.01.40.0010	Crankshaft	Jiang Ling493

Part Number	Name	Engine Model
B.A.01.13.0001	Piston	S4S
B.A.01.13.0002	Liner	S4S
B.A.01.13.0003	Piston Ring	S4S
B.A.01.13.0011	Engine Repair Kit	S4S
B.A.01.13.0006	Crankshaft Bearing	S4SSTD/+25/+50/+75
B.A.01.13.0007	Connecting Rod Bearing	S4SSTD/+25/+50/+75
B.A.01.13.0010	Thrust Washer	S4S
B.A.02.13.0001	Valve	S4S
B.A.02.13.0004	Valve Ring	S4S
B.A.02.13.0005	Valve Guide	S4S
B.A.01.13.0014	Crankshaft	S4S

Part Number	Name	Engine Model
B.A.01.15.0004	Piston	Td27 30
B.A.01.15.00011	Liner	TD27
B.A.01.15.0006	Piston Ring	TD27/3MM
B.A.01.15.0014	Engine Repair Kit	TD27
B.A.01.15.0009	Crankshaft Bearing	TD27STD/+25/+50/+75
B.A.01.15.0010	Connecting Rod Bearing	TD27STD/+25/+50/+75
B.A.01.15.0011	Thrust Washer	TD27STD
B.A.02.15.0001	Valve	TD27
B.A.02.15.0003	Valve Ring	TD27
B.A.02.15.0005	Valve Guide	TD27
B.A.01.15.0018	Crankshaft	TD27

Part Number	Name	Engine Model
B.A.01.09.0002	Piston	4D94E
B.A.01.09.0001	Liner	4D94E
B.A.01.09.0004	Piston Ring	4D94E
B.A.01.09.0007	Engine Repair Kit	4D94E
B.A.01.09.0010	Crankshaft Bearing	4D94ESTD/+25/+50/+75
B.A.01.09.0011	Connecting Rod Bearing	4D94ESTD/+25/+50/+75
B.A.01.09.0026	Thrust Washer	4D94ESTD
B.A.02.09.0001	Valve	4D94E
B.A.02.09.0004	Valve Ring	4D94E
B.A.02.09.0006	Valve Guide	4D94E
B.A.01.09.0008	Crankshaft	4D94E

www.arslanforklift.com

Motor Tamir Kitleri

◆ Motor Tamir Kitleri

▶ Engine Repair Kit

Part Number	Name	Engine Model
B.A.01.19.00001	Piston & Liner Assembly	Xinchai490B
B.A.01.19.0012	Engine Repair Kit	Xinchai490B/A490/C490
B.A.01.19.0008	Crankshaft Bearing	Xinchai490B/A490/C490
B.A.01.19.0009	Connecting Rod Bearing	Xinchai490B/A490/C490
B.A.01.19.0010	Thrust Washer	Xinchai490B/A490/C490
B.A.01.19.0014	Cylinder Gasket	Xinchai490B/A490/C490
B.A.02.17.0008	Valve Parts	Xinchai490B/A490/C490
B.A.01.19.00051	Crankshaft Oil Seal	Xinchai490B/A490/C490
B.A.01.19.0007	Crankshaft	Xinchai490B/C490

Connecting Rod (Part Number)	Engine Model
B.A.02.02.0017	Isuzu C240
B.A.02.03.0010	Isuzu 4JG2
B.A.02.04.0020	Isuzu 6BG1
B.A.02.13.0008	Mitsubishi s4s
B.A.02.01.0051	Toyota 1DZ-2
B.A.02.15.0010	Nissan TD27
B.A.02.14.0008	Hyundai D4BB
B.A.02.09.0009	Yanmar 4D94E
B.A.02.08.0005	Nissan K25
B.A.02.190.0015	Quanchai490
B.A.01.19.0026	XinchaiA/C490

Part Number	Name	Engine Model
B.A.01.190.0001	Piston & Liner Assembly	Quanchai490
B.A.01.190.00041	Engine Repair Kit	Quanchai490
B.A.01.190.0002	Crankshaft Bearing	Quanchai490
B.A.01.190.0003	Connecting Rod Bearing	Quanchai490
B.A.01.190.0006	Thrust Washer	Quanchai490
B.A.01.190.0005	Cylinder Gasket	Quanchai490
B.A.02.190.0001	Valve	Quanchai490
B.A.02.190.0003	Valve Ring	Quanchai490
B.A.02.190.0005	Valve Guide	Quanchai490
B.A.01.190.0011	Crankshaft O-ring	Quanchai490
B.A.01.190.0007	Crankshaft	Quanchai490

Connecting Rod (Part Number)	Engine Model
B.A.01.02.0008	Isuzu C240
B.A.01.03.0011	Isuzu 4JG2
B.A.01.04.0015	Isuzu 6BG1
B.A.01.13.0015	Mitsubishi s4s
B.A.01.01.0008	Toyota 1DZ-2
B.A.01.15.0016	Nissan TD27
B.A.01.09.0009	Yanmar 4D94E
B.A.01.08.0017	Nissan K25
B.A.01.07.0018	Nissan K21
B.A.01.05.0017	Nissan H20-2
B.A.01.19.0015	490

Part Number	Name	Engine Model
B.A.01.23.0003Y	Piston & Liner Assembly	Dachai498
B.A.01.23.0018	Piston	Dachai498
B.A.01.23.0002Y	Engine Repair Kit	Dachai498
B.A.01.23.0008Y	Crankshaft Bearing	Dachai498
B.A.01.23.0010Y	Connecting Rod Bearing	Dachai498
B.A.01.23.0014	Thrust Washer	Dachai498
B.A.02.230.0001	Valve	Dachai498
B.A.02.230.0005	Valve Ring	Dachai498
B.A.02.230.0009	Valve Guide	Dachai498
B.A.01.23.0031	Crankshaft	Dachai498

www.arslanforklift.com

Motor Tamir Kitleri

◆ Motor Tamir Kitleri

▶ Engine Repair Kit

Connecting Rod (Part Number)	Engine Model
B.A.01.02.0042	Isuzu C240
B.A.01.03.0020	Isuzu 4JG2
B.A.01.04.0032	Isuzu 6BG1
B.A.01.15.0012	Nissan TD27
B.A.01.13.0013	Mitsubishi s4s
B.A.01.09.0019	Yanmar 4D94E
B.A.01.08.0012	Nissan K25
B.A.01.14.0050	Hyundai D4BB
B.A.01.11.0014	Toyota 4Y
B.A.01.01.0018	Toyota 1DZ-2
B.A.01.19.0031	Xinchai490

Connecting Rod (Part Number)	Engine Model
B.A.05.13.0001	C240
B.A.05.13.0002	4JG2
B.A.05.13.0004	TCM/TD27Automatic Transmission
B.A.05.13.00069	4D94E
B.A.05.13.0012	K25 Manual Transmission
B.A.05.13.00070	H20/H25Manual Transmission
B.A.05.13.0005	H20/H25Automatic Transmission
B.A.05.13.0003	7/8F4Y Automatic Transmission
B.A.05.13.00071	7/8F1DZ Automatic Transmission
B.A.05.13.00072	7/8F1DZ Manual Transmission
B.A.01.19.0025	Xinchai490
B.A.05.13.0014	Xinchai498

Part Number	Engine Model
B.A.01.02.0010	C240
B.A.01.03.0050	4JG2
B.A.01.04.0040	6BG1
B.A.01.05.0050	H20-II/K21
B.A.01.15.0050	TD27
B.A.01.19.0050	490BPG

Part Number	Engine Model
B.A.01.01.0017	1DZ-2
B.A.01.02.0025	C240
B.A.01.03.0022	4JG2
B.A.01.04.0009	6BG1
B.A.01.05.0013	H20-II
B.A.01.07.0009	K21/K25
B.A.01.09.0007	4D94E/4TNE94
B.A.01.13.0011	S4S
B.A.01.130.0007	S6S
B.A.01.14.0006	D4BB
B.A.01.15.0014	TD27
B.A.01.17.0007	4D98E/4TNE98

Part Number	Engine Model
B.A.01.01.0010	1DZ-2
B.A.01.02.0041	C240
B.A.01.03.0010	4JG2
B.A.01.04.0020	6BG1
B.A.01.07.0011	K15/H20-2/K21
B.A.01.08.0011	K25
B.A.01.09.0008	4D94E
B.A.01.13.0014	S4S
B.A.01.15.0018	TD27
B.A.01.19.0007	Xinchai490B/A
B.A.01.19.0073	Xinchai C490
B.A.01.23.0031	Dachai498
B.A.01.31.0013	Chaochai6102

www.arslanforklift.com

Marş Motorları

◆ Marş Motorları

H20

Part Number: B.A.05.09.0007
Engine Model: Nissan H20-2
Parameter: 12V 8 Teeth

H25

Part Number: B.A.05.09.0008
Engine Model: Nissan H25
Parameter: 12V 9 Teeth

K21/25

Part Number: B.A.05.09.0009
Engine Model: Nissan K21/K25
Parameter: 12V 9 Teeth

TD 27

Part Number: B.A.05.09.0005
Engine Model: Nissan TD27/Dachai 498
Parameter: 12V 9 Teeth

C240

Part Number: B.A.05.09.0004
Engine Model: Isuzu C240
Parameter: 12V 9 Teeth

4JG2

Part Number: B.A.05.09.0001
Engine Model: Isuzu 4JG2
Parameter: 12V 9 Teeth

www.arslanforklift.com

1DZ

Part Number: B.A.05.09.0011
Engine Model: Linde
Parameter: 12V 9 Teeth

4Y

Part Number: B.A.05.09.0015
Engine Model: Toyota4Y/5K
Parameter: 12V 9 Teeth

4D94E

Part Number: B.A.05.09.00061
Engine Model: Yanmar4D94E
Parameter: 12V 9 Teeth

H18

Part Number: B.A.05.09.0002
Engine Model: Mitsubishi S4S
Parameter: 12V 10 Teeth

Linde

Part Number: B.A.05.09.00028
Engine Model: Toyota1DZ/2Z/13Z
Parameter: 12V 11 Teeth

S4S

Part Number: B.A.05.09.0021
Engine Model: Linde
Parameter: 12V 10 Teeth

Alternatörler / Şarj Dinamoları

◆ Alternatörler / Şarj Dinamoları

C240

Part Number: B.A.05.10.0002
Engine Model: Isuzu C240

4JG2

Part Number: B.A.05.10.00061
Engine Model: Isuzu 4JG2

6BG1

Part Number: B.A.05.10.0018
Engine Model: Isuzu 6BG1

4D94E

Part Number: B.A.05.10.00031
Engine Model: Yanmar4D94E

K21/25

Part Number: B.A.05.10.0008
Engine Model: Nissan H20/K21/K25

TD27

Part Number: B.A.05.10.0004
Engine Model: Nissan TD27

1DZ

Part Number: B.A.05.10.0001
Engine Model: Toyota1DZ/2Z/13Z

498

Part Number: B.A.05.10.0012
Engine Model: Dachai498

H18

Part Number: B.A.05.10.0022
Engine Model: Linde

Linde

Part Number: B.A.05.10.0017
Engine Model: Linde

490

Part Number: B.A.05.10.00091
Engine Model: Xinchai 490

S4S

Part Number: B.A.05.10.00030
Engine Model: Mitsubishi S4S

www.arslanforklift.com

Motor Parçaları

◆ Distribütör / Karbüratör / Enjeksiyon Pompası

H20/K21/K25

Part Number: B.A.05.06.0001
Engine Model: Nissan K25

4Y

Part Number: B.A.05.06.0003
Engine Model: Toyota 4Y

K21/25

Part Number: B.A.05.05.0003
Engine Model: Nissan K21/25

H20

Part Number: B.A.05.05.0001
Engine Model: Nissan H20-2

4Y

Part Number: B.A.05.06.0004
Engine Model: Toyota 4Y

K25

Part Number: B.A.05.06.0007
Engine Model: Nissan K25

H20

Part Number: B.A.05.05.0004
Engine Model: Nissan H20-2

K21/K25

Part Number: B.A.05.05.00042
Engine Model: K21/K25

A/C490

Part Number: B.A.05.07.0054
Engine Model: XinchaiA/C490

490B

Part Number: B.A.05.07.00510
Engine Model: Xinchai 490B

490

Part Number: B.A.05.07.0053
Engine Model: Quanchai 490

498

Part Number: B.A.05.07.0050
Engine Model: Dachai 498

www.arslanforklift.com

Motor Parçaları

◆ Filtreler

C240

Part Number: B.A.04.05.0001
Engine Model: Isuzu C240

1DZ

Part Number: B.A.04.05.0009
Engine Model: Toyota 1DZ

S4S

Part Number: B.A.04.05.0003
Engine Model: Yanmar 4D94E

4S

Part Number: B.A.04.05.0002
Engine Model: Mitsubishis 4S

TD27

Part Number: B.A.04.05.0008
Engine Model: Nissan TD27

4D94E

Part Number: B.A.04.02.0051
Engine Model: Yanmar 4D94E

www.arslanforklift.com

Oil Filter & Fuel Filter

Part Number: B.A.04.02.HL02
Engine Model: Xinchai 490

Oil Filter & Fuel Filter

Part Number: B.A.04.02.0001
Engine Model: Isuzu C240

Oil Filter & Fuel Filter

Part Number: B.A.04.02.0008
Engine Model: Nissan TD27

Oil Filter & Fuel Filter

Part Number: B.A.04.02.0003
Engine Model: Mitsubishi S4S

Oil Filter & Fuel Filter

Part Number: B.A.04.02.0023
Engine Model: Yanmar 4D94E

Oil Filter & Fuel Filter

Part Number: B.A.04.02.0020
Engine Model: Perkins

CHANGYUAN Hidrolik Pompalar

◆ CHANGYUAN Hidrolik Pompalar

Gear Pump

Part Number	B.A.05.08.11.11061130
Forklift Model	"Steering PumpHELI,Hangcha"
Model Number	CBW-F306-ALBB

Gear Pump

Part Number	B.A.05.08.11.31181139
Forklift Model	"Walking PumpHELI 1-1.8T"
Model Number	CBHCB-F16-AL@

Gear Pump

Part Number	B.A.05.08.11.31181140
Forklift Model	"Walking PumpHELI 2-2.5T"
Model Number	CBHCB-F18-AL@

Gear Pump

Part Number	B.A.05.08.11.21201210
Forklift Model	"Lift PumpHELI 3T"
Model Number	CBTD-F416-AFH4

Gear Pump

Part Number	B.A.05.08.11.61161110
Forklift Model	"Lift PumpHangcha 1-2.5T"
Model Number	CBTDH-F416-ALH4

Gear Pump

Part Number	B.A.05.08.11.61201110
Forklift Model	"Lift PumpHangcha 3T"
Model Number	CBTDH-F420-ALH4

www.arslanforklift.com

Gear Pump

Part Number	B.A.05.08.02.11116130
Forklift Model	HELI 490
Model Number	CBT-F432-AFHL

Gear Pump

Part Number	B.A.05.08.02.21106131
Forklift Model	HELI H2000
Model Number	CBHZ-F3.15-ALH6L

Gear Pump

Part Number	B.A.05.08.03.14134025
Forklift Model	Linde
Model Number	CBTCA-G425-AF@

Gear Pump

Part Number	B.A.05.08.03.63123032
Forklift Model	HELI 5-7T
Model Number	CBK-G432-AF@

Gear Pump

Part Number	B.A.05.08.03.64123136
Forklift Model	HELI 8-10T
Model Number	CBKC-G436-AT@

Gear Pump

Part Number	B.A.05.08.03.91363501
Forklift Model	HELI 8-10
Model Number	CBHYA-G36/F3.5-AT@

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

CHANGYUAN Hidrolik Pompalar

◆ CHANGYUAN Hidrolik Pompalar

Product Name	Model Number	Displacement	Teeth	Hydraulic Port		Model
Gear Pump	CBWH-F304-ALB	4	Flat Teeth	Screw Joint	√	Hangcha/
Gear Pump	CBW-F306-ALBB	6	Flat Teeth	Screw Joint	√	HELI/Hangcha
Gear Pump	CBTD-F416-AFH	16	4 Teeth	Flanged Joint	√	HELI
Gear Pump	CBTD-F420-AFH	20	4 Teeth	Flanged Joint	√	HELI
Gear Pump	CBTD-F416-ALH4	16	4 Teeth	Screw Joint	√	Liugong
Gear Pump	CBTD-F420-ALH4	20	4 Teeth	Screw Joint	√	Liugong
Gear Pump	CBHCB-F14.5-AL Φ	14.5	10 Teeth	Screw Joint	√	HELI
Gear Pump	CBHCB-F16-AL Φ	16	10 Teeth	Screw Joint	√	HELI
Gear Pump	CBHCB-F18-AL Φ	18	10 Teeth	Screw Joint	√	HELI
Gear Pump	CBHCB-F20-AL Φ	20	10 Teeth	Screw Joint	√	HELI
Gear Pump	CBHCBA-F25-AL Φ	25	10 Teeth	Screw Joint	√	
Gear Pump	CBTDHD-F16-AF ϕ	16	10 Teeth	Flanged Joint		Doosan
Gear Pump	CBTDHA-F18-AL ϕ	18	10 Teeth	Screw Joint		ATF/TCM
Gear Pump	CBTDHE-F16-TL ϕ	16	10 Teeth	Screw Joint		Hangcha
Gear Pump	CBTDHE-F20-TL ϕ	20	10 Teeth	Screw Joint		Hangcha
Gear Pump	CBTDHB-F416-ALH4	16	4 Teeth	Screw Joint		Tailift
Gear Pump	CBTDHB-F418-ALH4	18	4 Teeth	Screw Joint		Tailift
Gear Pump	CBTDHB-F420-Al ϕ	20	10 Teeth	Screw Joint		Tailift
Gear Pump	CBHCN-F16-ALH4	16	4 Teeth	Screw Joint		Hangcha
Gear Pump	CBHCN-F20-ALH4	20	4 Teeth	Screw Joint		Hangcha
Gear Pump	CBTDH-F416-ALH4	16	4 Teeth	Screw Joint		Hangcha/Tailift
Gear Pump	CBTDH-F420-ALH4	20	4 Teeth	Screw Joint		Hangcha
Gear Pump	CBTDHW-F16-AL Φ	16	10 Teeth	Screw Joint	√	
Gear Pump	CBTDHBA-F420-AL ϕ	20	10 Teeth	Screw Joint	√	Tailift

Part Number	Product Name	Model Number
B.A.05.08.24.A02216A	Shimadzu Gear Pump	DSG05-16F2H9-L181T
B.A.05.08.24.A11120A	Shimadzu Gear Pump(TEU)	DSG05A20F9H1-R223C
B.A.05.08.24.A21123A	Shimadzu Gear Pump(TEU)	DSG05C23F9H1-R213C
B.A.05.08.24.A21124A	Shimadzu Gear Pump(TEU)	DSG05C23F9H1-R265C
B.A.05.08.24.A21114A	Shimadzu Gear Pump(HELI)	DSG05C14.5F9H1-R020C
B.A.05.08.24.A21116A	Shimadzu Gear Pump(HELI)	DSG05C16F9H1-R016C
B.A.05.08.24.A21118A	Shimadzu Gear Pump(HELI)	DSG05C18F9H1-R015C
B.A.05.08.24.A21120A	Shimadzu Gear Pump(HELI)	DSG05C20F9H1-R237C
B.A.05.08.24.A21125A	Shimadzu Gear Pump(HELI)	DSG05C25F9H1-R019CH
B.A.05.08.24.A21216A	Shimadzu Gear Pump (Hangcha)	DSG05C16F9H9-R261C
B.A.05.08.24.A21121A	Shimadzu Gear Pump(Hangcha)	DSG05C20F9H9-R269C
B.A.05.08.24.A11116A	Shimadzu Gear Pump(Youen)	DSG05A16F9H1-R004C
B.A.05.08.24.A11118A	Shimadzu Gear Pump(Maximal)	DSG05A18F9H1-R270T
B.A.05.08.24.A11220A	Shimadzu Gear Pump(Liugong)	DSG05A20F9H9-R229
B.A.05.08.24.A13220A	Shimadzu Gear Pump(Baoli)	DSG05A20F1H9-L224C
B.A.05.08.24.A23216A	Shimadzu Gear Pump(Baoli)	DSG05C16F1H9-R228C
B.A.05.08.24.A21220A	Shimadzu Gear Pump(Tailift/Hecha)	DSG05C20F9H9-R221C

www.arslanforklift.com

Kontrol Valfleri

◆ Kontrol Valfleri

Control Valve

Part Number	B.C.04.03.1302
Forklift Model	HL/HC 1-3T
Model Number	CBD2-F15-02

Control Valve

Part Number	B.C.04.03.7102
Forklift Model	HL/HC 2-3T
Model Number	CDB2-F15DE-02

Control Valve

Part Number	B.C.04.03.3203
Forklift Model	HL Diesel 3T
Model Number	CDB3-F15Y1-03

www.arslanforklift.com

Control Valve

Part Number	B.C.04.05.0217
Forklift Model	TCMFB20-7
Model Number	MSV04-3124-50-01

Control Valve



Part Number	B.C.04.05.4006
Forklift Model	HL G Series
Model Number	MSV04-3125-57-01H

Control Valve

Part Number	B.C.04.05.1102
Forklift Model	HL CPDS
Model Number	MSV04-212-82-02H

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Kontrol Valfleri

◆ Kontrol Valfleri

Product Name	Model Number	Applied Forklift
Control Valve	CDB2-F15DE-02	HL (DC) 2-3T 2 valve
Control Valve	CDB2-F15DE-03	HL (DC) 2-3T 3 valve
Control Valve	CDB2-F15DE-04	HL (DC) 2-3T 4 valve
Control Valve	CBD2-F15DC-02	HC (DC) 2-3T 2 valve
Control Valve	CBD2-F15DC-03	HC (DC) 2-3T 3 valve
Control Valve	CBD2-F15DC-04	HC (DC) 2-3T 4 valve
Control Valve	CDB2-F15DC1-02	Hyundai (DC) 2-3T 2 valve
Control Valve	CDB2-F15DC1-03	Hyundai (DC) 2-3T 3 valve
Control Valve	CDB2-F15DC1-04	Hyundai (DC) 2-3T 4 valve
Control Valve	CDB2-F15D-02	Liugong (DC) 2-3T 2 valve
Control Valve	CDB2-F15D-03	Liugong (DC) 2-3T 3 valve
Control Valve	CDB2-F15D-04	Liugong (DC) 2-3T 4 valve
Control Valve	CDA4-F15-02	Hyundai2-3.5T 2 valve
Control Valve	CDA4-F15-03	Hyundai2-3.5T 3 valve
Control Valve	CDA4-F15-04	Hyundai2-3.5T 4 valve

www.arslanforklift.com

Control Valve	Model Number	OEM	MODEL
Control Valve	MSV04-212-50F	534A2-40402	TCMZ5/T6 2-3T 2 valve
Control Valve	MSV04-3124-51F	534A2-40502	TCMZ5/T6 2-3T 3 valve
Control Valve	MSV04-41244-51F	534A2-40602	TCMZ5/T6 2-3T 4 valve
Control Valve	MSV04-212-55-01	277P7-30201	TCMFB20/30-7 2 valve
Control Valve	MSV04-3124-50-01	277P7-30301	TCMFB20/30-7 3 valve
Control Valve	MSV04-41211-50-1	277P7-30401	TCMFB20/30-7 4 valve
Control Valve	MSV04-3331-50-01	HC278M7-30012	TCMFRB15-6 3 valve
Control Valve	MSV04-212-58F-01	A20A7-30421	HL Diesel 2-3.5T 2 valve
Control Valve	MSV04-3123-54F-01	A20A7-30431	HL Diesel 2-3.5T 3 valve
Control Valve	MSV04-41235-51F-01	A20A7-30441	HL Diesel 2-3.5T 4 valve
Control Valve	MSV04-212-95-02	A65S7-30021	HL (DC) 2-3T 2 valve
Control Valve	MSV04-3123-95-02	A65S7-30031	HL (DC) 2-3T 3 valve
Control Valve	MSV04-41235-95-02	A65S7-30041	HL (DC) 2-3T 4 valve
Control Valve	MSV04-212-68	A63V7-30001	HL (AC) 2-3T 2 valve
Control Valve	MSV04-3123-64	A63V7-30011	HL (AC) 2-3T 3 valve
Control Valve	MSV04-41235-58	A63V7-30021	HL (AC) 2-3T 4 valve
Control Valve	MSV04-212-82-01	A7G57-30201	HL (G Series) 2 valve
Control Valve	MSV04-3125-57-01	A7G57-30301	HL (G Series) 3 valve
Control Valve	MSV04-41235-53-01	A7G57-30401	HL (G Series) 4 valve

Orbitrol

◆ Orbitrol

Orbitrol

Part Number	B.C.02.01.60.1256
Forklift Model	HL/HC 3T
Model Number	BZZ1-E125-BA

Orbitrol

Part Number	B.C.02.01.70.1253
Forklift Model	Tailift 3T
Model Number	BZZ1-E100-BB

Orbitrol

Part Number	B.C.02.01.61.1257
Forklift Model	HL/HC
Model Number	BZZ5-125-BA

Orbitrol

Part Number	B.C.02.01.55.1003
Forklift Model	HL/HC
Model Number	BZZ1-E125BA/FK

Orbitrol

Part Number	B.C.02.01.60.1601
Forklift Model	HL/HC 4T
Model Number	BZZ1-E160-CA

Orbitrol

Part Number:	B.C.02.01.60.0003
Forklift Model:	HL/HC 5-7T
数据信息:	BZZ1-E200-BA

Orbitrol

Part Number	B.C.02.01.00031
Forklift Model	TCMT6
Model Number	532-1332/BZZ-100

Orbitrol

Part Number	B.C.02.01.00032
Forklift Model	TCMT3C
Model Number	532-1382/BZZ-100

Orbitrol

Part Number	B.C.02.01.60.2802
Forklift Model	HL/HC8-10T
Model Number	BZZ1-E280-BA

Orbitrol

Part Number	B.C.02.01.60.2801
Forklift Model	HL/HC8-10T
Model Number	BZZ1-E280-CA

Orbitrol

Part Number	B.C.02.01.2001
Forklift Model	Komatsu 3T
Model Number	532-1382-19/BZZ-100

Orbitrol

Part Number	B.C.02.01.55.1002
Forklift Model	HL/HC AC
Model Number	102S-5-125-07-H

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Hidrolik Silindir

◆ Hidrolik Silindir

Hydraulic Cylinder

Part Number: B.D.03.02.0101
Forklift Model: HL H2000 2-2.5T

Hydraulic Cylinder

Part Number: B.B.01.09.0108
Forklift Model: HL H2000 2-2.5T

Hydraulic Cylinder

Part Number: B.D.03.02.0108
Forklift Model: HL 3T

Hydraulic Cylinder

Part Number: B.B.01.092.01091
Forklift Model: HELI G Series 3T

Hydraulic Cylinder

Part Number: B.D.03.02.0004
Forklift Model: TCMFRB15-6

Hydraulic Cylinder

Part Number: B.B.01.03.0042
Forklift Model: TCMFB15-7/V

www.arslanforklift.com

Radyatör

◆ Radyatör

Radiator

Part Number	B.A.06.01.57.1001
Forklift Model	HL H2000/490
Model Number	H93D2-12101

Radiator

Part Number	B.A.06.01.57.1003
Forklift Model	HL @/490
Model Number	A91B2-10201

Radiator

Part Number	B.A.06.01.57.1007
Forklift Model	HC 30HB
Model Number	30HB-331000A

Radyatör

◆ Radyatör

Radiator

Part Number	B.A.06.01.57.1005
Forklift Model	HC 30N/490
Model Number	N160-331000-000

Radiator

Part Number	B.A.06.01.57.1013
Forklift Model	H2000/Dachai 498
Model Number	H99Z2-10201

Radiator

Part Number	B.A.06.01.57.1009
Forklift Model	Tailift/490
Model Number	92510418

Radiator

Part Number	B.A.06.01.51.2220
Forklift Model	H2000/Dachai 498
Model Number	H99Z2-10201

Radiator

Part Number	B.A.06.01.51.2210
Forklift Model	H2000/490
Model Number	H93D2-12101

Radiator

Part Number:	B.A.06.01.51.1501
Forklift Model:	HL /NB485 1.5T
数据信息:	H15D2-10201

www.arslanforklift.com

Radiator

Part Number	B.A.06.01.53.3105
Forklift Model	TCMT6/C240
Model Number	HC234B2-10102

Radiator

Part Number	B.A.06.01.58.1001
Forklift Model	JAC/490
Model Number	C0F96-05202

Radiator

Part Number	B.A.06.01.55.3110
Forklift Model	Dalian/490
Model Number	30XDA-10101

Radiator

Part Number	B.A.06.01.03.34210
Forklift Model	HELI H2000 Xichai 4110
Model Number	H04X2-10101

Radiator

Part Number	B.A.06.01.03.33210
Forklift Model	HELI H2000 Chaochai 6102
Model Number	H08E2-10201

Radiator

Part Number	B.A.06.01.03.43210
Forklift Model	HELI H2000 Isuzu 6GB1
Model Number	H56J2-10801

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Radyatör

◆ Radyatör

Part Number	Model Number	Applied Forklift
B.A.06.01.06.20110	50W-332000	HC 50-70H CY6102/6BG1
B.A.06.01.06.20210	50V-332000	HC 50-70H LR4108G10Y
B.A.06.01.06.20310	50DHA-332000	HC 50-70H LR4105
B.A.06.01.06.40110	R450-331000-000	HC 40-50R LR4108
B.A.06.01.06.40210	R453-331000-000	HC 40-50R TD42
B.A.06.01.06.50110	80DH-332000	HC 50-100R CY6102BG-2
B.A.06.01.07.10110	HC232Z2-10201S	TCMATF/V300 490
B.A.06.01.07.20110	HC237Z2-10301T	TCM/700 C240/4JG2
B.A.06.01.07.20210	HC234B2-10101S	TCM/700 C240/4JG2
B.A.06.01.07.30110	HC236L2-10102T	TCMT6 TD27/498
B.A.06.01.07.30310	HC234B2-10002S	TCMT6 C240
B.A.06.01.07.30410	HC233B2-10002	TCMT6 H25
B.A.06.01.07.50410	HC230C2-10201	TCM/5-10T6BG1
B.A.06.01.03.32210	H43E2-10202	HL H2000 6BG1
B.A.06.01.03.33210	H08E2-10201	HL H2000 6102BG
B.A.06.01.03.34210	H04X2-10101	HL H2000 5-7T CA4110
B.A.06.01.03.35210	H05H2-10201	HL H2000 5-7T CA6110/125/
B.A.06.01.03.36210	H09E2-10201	HL H2000 5-7T R4105
B.A.06.01.03.37210	H42X2-10201	HL H2000 5-7T S6S-T
B.A.06.01.03.38210	A37D2-10205	HL 4-5T
B.A.06.01.03.43210	H56J2-10801	HL H2000 6102BG
B.A.06.01.03.4501	AJ012-10101	HL 4-5TK 4D35G
B.A.06.01.03.45210	H05J2-10211	HL H2000 8-10T CA6110/125/
B.A.06.01.03.53210	K0U02-10221	HL 5-7T 6102BG
B.A.06.01.03.55210	K0Q82-10201	HL CA6110/125
B.A.06.01.03.73210	25782-10201	HL 5-7T 6102BG
B.A.06.01.03.75210	A09X2-10211	HL 5-7T CA6110/125/

www.arslanforklift.com

Su Pompası / Devirdaim

◆ Su Pompası / Devirdaim

C240

Part Number: B.A.06.02.0002
Engine Model: Isuzu C240

4JG2

Part Number: B.A.06.02.0004
Engine Model: Isuzu 4JG2

6BG1

Part Number: B.A.06.02.0012
Engine Model: Isuzu 6BG1-QC02

Nissan TD27

Part Number: B.A.06.02.0011
Engine Model: Nissan TD27

K21/25

Part Number: B.A.06.02.0007
Engine Model: Nissan K21/K25

1DZ/2Z/13Z

Part Number: B.A.06.02.0009
Engine Model: Toyota 1DZ/2Z/13Z

4D94E

Part Number: B.A.06.02.0005
Engine Model: Yanmar 4D94E

4TNV94L

Part Number: B.A.06.02.0023
Engine Model: 4TNV94L

490

Part Number: B.A.06.02.00161
Engine Model: Xinchai 490

490

Part Number: B.A.06.02.00183
Engine Model: Quanchai 490

498

Part Number: B.A.06.02.00165
Engine Model: Dachai 498

D4BB

Part Number: B.A.06.02.0015
Engine Model: Hyundai D4BB

www.arslanforklift.com

Fan & Fan Bıçakları

◆ Fan / Fan Bıçakları

490

Part Number: B.A.06.11.0016
Engine Model: Xinchai 490

498

Part Number: B.A.06.11.0026
Engine Model: Dachai 498

F2/FE

Part Number: B.A.06.11.0011
Engine Model: Mazda FE

1DZ

Part Number: B.A.06.11.0003
Engine Model: Toyota 1DZ/4D94E

K21/25

Part Number: B.A.06.11.0009
Engine Model: Nissan K21/K25

6BG1

Part Number: B.A.06.11.0005
Engine Model: 6BG1 Ø420

S4S

Part Number: B.A.06.11.0008
Engine Model: Mitsubishi S4S

S4S

Part Number: B.A.06.11.0007
Engine Model: Mitsubishi S4S

S4S

Part Number: B.A.06.11.0006
Engine Model: Mitsubishi S4S

C240

Part Number: B.A.06.11.0001
Engine Model: Isuzu C240

4JG2

Part Number: B.A.06.11.0002
Engine Model: Nissan TD27

6BG1

Part Number: B.A.06.11.0004
Engine Model: Toyota 6BG1

www.arslanforklift.com

Fren Ana Silindiri

◆ Fren Ana Silindiri

Cylinder Master Cylinder

Part Number: B.B.03.01.0013
Forklift Model: HC 30HB

Cylinder Master Cylinder

Part Number: B.B.03.01.00132
Forklift Model: HC 30N

Cylinder Master Cylinder

Part Number: B.B.03.01.0012
Forklift Model: HL 3T

Cylinder Master Cylinder

Part Number: B.B.03.01.00121
Forklift Model: HL CQD16-20

Cylinder Master Cylinder

Part Number: B.B.03.01.00122
Forklift Model: HL 4.5T

Cylinder Master Cylinder

Part Number: B.B.03.01.00110
Forklift Model: HL 5-10T

Cylinder Master Cylinder

Part Number: B.B.03.01.0025
Forklift Model: HL 5-7T

Cylinder Master Cylinder

Part Number: B.B.03.01.00133
Forklift Model: JAC 3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0003
Forklift Model: TCMT6 2-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0001
Forklift Model: TCMFB10-30

Cylinder Master Cylinder

Part Number: B.B.03.01.0020
Forklift Model: Hyundai 1-4T

Cylinder Master Cylinder

Part Number: B.B.03.01.0014
Forklift Model: HC 30J

www.arslanforklift.com

Fren Ana Silindiri

◆ Fren Ana Silindiri

Cylinder Master Cylinder

Part Number: B.B.03.01.00021
Forklift Model: Lsuzu 5/6F 1-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0002
Forklift Model: Lsuzu 7/8F1-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0008
Forklift Model: Komatsu 2-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0009
Forklift Model: Komatsu 14 2-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.0006
Forklift Model: Komatsu 16 2-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.00091
Forklift Model: Komatsu 11

Cylinder Master Cylinder

Part Number: B.B.03.01.0004
Forklift Model: Mitsubishi

Cylinder Master Cylinder

Part Number: B.B.03.01.0019
Forklift Model: Mitsubishi 4T

Cylinder Master Cylinder

Part Number: B.B.03.01.0007
Forklift Model: Tailift 1-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.00010
Forklift Model: Nichiyu 1-3T

Cylinder Master Cylinder

Part Number: B.B.03.01.001221
Forklift Model: Lsuzu 7FD50

Cylinder Master Cylinder

Part Number: B.B.03.01.001101
Forklift Model: TCMZ8 5-10T

www.arslanforklift.com

Fren Teker Silindiri

◆ Fren Teker Silindiri

Cylinder Master Cylinder

Part Number: B.B.03.02.0011
Forklift Model: HC 30HB

Cylinder Master Cylinder

Part Number: B.B.03.02.00110
Forklift Model: HC 15-20HB

Cylinder Master Cylinder

Part Number: B.B.03.02.00071
Forklift Model: HC 20-25A

Cylinder Master Cylinder

Part Number: B.B.03.02.00091
Forklift Model: HL 3T

Cylinder Master Cylinder

Part Number: B.B.03.02.00081
Forklift Model: HL 2.5T

Cylinder Master Cylinder

Part Number: B.B.03.02.00093
Forklift Model: HL 1.5T

www.arslanforklift.com

Cylinder Master Cylinder

Part Number: B.B.03.02.0001
Forklift Model: TCM1.5T

Cylinder Master Cylinder

Part Number: B.B.03.02.0018
Forklift Model: TCM2-3T

Cylinder Master Cylinder

Part Number: B.B.03.02.000951
Forklift Model: TCM4.5T

Cylinder Master Cylinder

Part Number: B.B.03.02.00291
Forklift Model: TCM8-10T

Cylinder Master Cylinder

Part Number: B.B.03.02.0029
Forklift Model: TCM8-10T Right

Cylinder Master Cylinder

Part Number: B.B.03.02.0028
Forklift Model: TCM8-10T Left

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Fren Teker Silindiri

◆ Fren Teker Silindiri

Cylinder Master Cylinder

Part Number：B.B.03.02.00095
Forklift Model：HL 4.5T

Cylinder Master Cylinder

Part Number：B.B.03.02.00094
Forklift Model：HL 5–7T

Cylinder Master Cylinder

Part Number：B.B.03.02.0003
Forklift Model：Toyota 7F/8F 3T

Cylinder Master Cylinder

Part Number：B.B.03.02.0006
Forklift Model：Komatsu 14代2–3T

Cylinder Master Cylinder

Part Number：B.B.03.02.00041
Forklift Model：Komatsu 16 2–3T

Cylinder Master Cylinder

Part Number：B.B.03.02.0004
Forklift Model：Mitsubishi F18C

Cylinder Master Cylinder

Part Number：B.B.03.02.0002
Forklift Model：Nichiyu

Cylinder Master Cylinder

Part Number：B.B.03.07.00242
Forklift Model：HELI CQD16/20

Cylinder Master Cylinder

Part Number：B.B.03.02.000941
Forklift Model：TCMZ8 5–7T

www.arslanforklift.com

Fren Pabucu

◆ Fren Pabucu

Brake Shoe

Part Number: B.B.03.08.00111
Forklift Model: HL 1.5T

Brake Shoe

Part Number: B.B.03.08.00202
Forklift Model: HL 2.5T

Brake Shoe

Part Number: B.B.03.08.00151
Forklift Model: HL 3T

Brake Shoe

Part Number: B.B.03.08.00203
Forklift Model: HL 4.5T

Brake Shoe

Part Number: B.B.03.08.00204
Forklift Model: HL 5-7T

Brake Shoe

Part Number: B.B.03.08.00205
Forklift Model: HL 8-10T

Brake Shoe

Part Number: B.B.03.08.0014
Forklift Model: TCMFB15-7/V

Brake Shoe

Part Number: B.B.03.08.0011
Forklift Model: TCMFB2-3T Electric

Brake Shoe

Part Number: B.B.03.08.00191
Forklift Model: TCMFRB15-6

Brake Shoe

Part Number: B.B.03.08.002041
Forklift Model: TCMZ8 5-7T

Brake Shoe

Part Number: B.B.03.08.002051
Forklift Model: TCMZ8 8-10T

Brake Shoe

Part Number: B.B.03.08.00111
Forklift Model: Nichiyu

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Fren Pabucu & Fren Montajlı

◆ Fren Pabucu & Fren Montajlı

Brake Shoe

Part Number: B.B.03.08.0002
Forklift Model: Komatsu 14 2-3T

Brake Shoe

Part Number: B.B.03.08.0003
Forklift Model: Komatsu 16 2-3T

Brake Shoe

Part Number: B.B.03.08.0041
Forklift Model: Hyster 2-3T

Brake Shoe

Part Number: B.B.03.08.0001
Forklift Model: Toyota 7/8F 2-3T

Brake Shoe

Part Number: B.B.03.08.0019
Forklift Model: Toyota 7FRB15

Brake Shoe

Part Number: B.B.03.08.0013
Forklift Model: Tailift 2-3T

www.arslanforklift.com

Brake Shoe

Part Number: B.B.03.08.0012
Forklift Model: Tailift

Brake Assembly

Part Number: B.B.03.07.0013
Forklift Model: HC CDQ14-16H
used on Motor of HC Reach

Brake Assembly

Part Number: B.B.03.07.0024
Forklift Model: HL CQD16/20
used on Load Wheel

Brake Assembly

Part Number: B.B.03.07.0010
Forklift Model: HL 1.5T

Brake Assembly

Part Number: B.B.03.07.00031
Forklift Model: HL 2-2.5T

Brake Assembly

Part Number: B.B.03.07.00011
Forklift Model: HL 3T

Link & Link Pinleri

◆ Link & Link Pinleri

Link & Link Pin

Part Number: B.B.01.09.00152
Forklift Model: HL H2000 1–1.8T

Link & Link Pin

Part Number: B.B.01.091.0004
Forklift Model: HL 2–3T

Link & Link Pin

Part Number: B.B.01.092.0003
Forklift Model: HL G 3T

Link & Link Pin

Part Number: B.B.01.05.0005
Forklift Model: Tailift 2–3.5T

Link & Link Pin

Part Number: B.B.01.11.0016
Forklift Model: HC 30N

Link & Link Pin

Part Number: B.B.05.10.03
Forklift Model: HC 30J

Link & Link Pin

Part Number: B.B.01.03.0019
Forklift Model: TCMT6

Link & Link Pin

Part Number: B.B.05.08.01
Forklift Model: TCMFD20/25 TC3

Link & Link Pin

Part Number: B.B.01.03.0023
Forklift Model: TCMFD30 T3C

Link & Link Pin

Part Number: B.B.01.04.0004
Forklift Model: Mitsubishi F18C

Link & Link Pin

Part Number: B.B.01.24.0012
Forklift Model: Hyster H3.0

Link & Link Pin

Part Number: B.B.01.02.0005
Forklift Model: Komatsu 16 2–3T

www.arslanforklift.com

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Akson

◆ Akson

Knuckle

Part Number: B.B.01.090.0010
Forklift Model: HL 2–3T L/R

Knuckle

Part Number: B.B.01.09.0009
Forklift Model: HL H2000 L/R

Knuckle

Part Number: B.B.01.092.0002
Forklift Model: HL G 3T L/R

Knuckle

Part Number: B.B.01.11.0007
Forklift Model: HC 30N L/R

Knuckle

Part Number: B.B.01.11.0105
Forklift Model: HC 30HB L/R

Knuckle

Part Number: B.B.01.03.0013
Forklift Model: TCMATF/T6 L/R

Knuckle

Part Number: B.B.01.03.0015
Forklift Model: TCMFD30T3C L/R

Knuckle

Part Number: B.B.01.07.0010
Forklift Model: Nichiyu FB15 L/R

Knuckle

Part Number: B.B.01.24.0011
Forklift Model: Hyster H L/R

Knuckle

Part Number: B.B.01.02.0027
Forklift Model: Komatsu 14 L/R

Knuckle

Part Number: B.B.01.02.0009
Forklift Model: Komatsu 16 L/R

Knuckle

Part Number: B.B.01.04.0011
Forklift Model: Mitsubishi L/R

www.arslanforklift.com

Akson Tamir Kitleri

◆ Akson Tamir Kitleri

Knuckle Repair Kit

Part Number: B.B.05.11.13
Forklift Model: HL 1–1.8T

Knuckle Repair Kit

Part Number: B.B.01.090.0013
Forklift Model: HL 2–3T

Knuckle Repair Kit

Part Number: B.B.01.093.0009
Forklift Model: HL K 3T

Knuckle Repair Kit

Part Number: B.B.01.09.0016
Forklift Model: HL H 2–3T

Knuckle Repair Kit

Part Number: B.B.01.092.0017
Forklift Model: HL G 3T

Knuckle Repair Kit

Part Number: B.B.01.03.0001
Forklift Model: TCM1–1.8T

www.arslanforklift.com

Knuckle Repair Kit

Part Number: B.B.01.091.0011
Forklift Model: TCM3T

Knuckle Repair Kit

Part Number: B.B.05.05.01
Forklift Model: HC 30N

Knuckle Repair Kit

Part Number: B.B.01.11.0006
Forklift Model: HC 30J

Knuckle Repair Kit

Part Number: B.B.01.05.0001
Forklift Model: Tailift 2–3.5T

Knuckle Repair Kit

Part Number: B.B.01.01.00011
orklift Model: Toyota 7/8F

Knuckle Repair Kit

Part Number: B.B.01.04.0101
Forklift Model: Mitsubishi

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Koltuk

◆ Koltuk

Seat

Part Number：B.F.01.01.0001
Forklift Model：HL/HC/TCM

Seat

Part Number：B.F.01.01.00011
Forklift Model：HL/HC/TCM
Shock–absorbing Function

Seat

Part Number：B.F.01.01.0006
Forklift Model：TCM/Toyota
Shock–absorbing Function

Seat

Part Number：B.F.01.01.0005
Forklift Model：HL H2000
Shock–absorbing Function, Armchair

Seat

Part Number：B.F.01.01.00012
Forklift Model：HL G Series
Shock–absorbing Function

Seat Safety Belt

Part Number：B.F.01.03.0001
Forklift Model：HL/HC/TCM/Toyota

www.arslanforklift.com

Gazlı Piston

◆ Gazlı Piston

Gas Spring

Part Number: B.F.06.01.0106
Forklift Model: HL H2000 1–1.8T

Gas Spring

Part Number: B.F.06.01.0106
Forklift Model: HL H2000 1–1.8T

Gas Spring

Part Number: B.F.06.01.0105
Forklift Model: HL K Series 3T

Gas Spring

Part Number: B.F.06.01.0109
Forklift Model: HL H Series 1–1.8T

Gas Spring

Part Number: B.F.06.01.0108
Forklift Model: HL H Series 2–2.5T

Gas Spring

Part Number: B.F.06.01.0107
Forklift Model: HL H Series 3T

www.arslanforklift.com

Gas Spring

Part Number: B.F.06.01.0104
Forklift Model: HL@2–3T

Gas Spring

Part Number: B.F.06.01.0112
Forklift Model: HL G Series 3T Left

Gas Spring

Part Number: B.F.06.01.0113
Forklift Model: HL G Series 3T

Part Number	Forklift Model
B.F.06.01.0001	TCMT3C
B.F.06.01.00011	TCMT6
B.F.06.01.0011	Komatsu FD30–16
B.F.06.01.0015	Toyota 7FB1–3T Left safety catch
B.F.06.01.0016	Toyota 7FB1–3T Right
B.F.06.01.0017	Toyota 7FD/G1–4.5T Left safety catch
B.F.06.01.0018	Toyota 7FD/G1–4.5T Right
B.F.06.01.0033	Tailift 2–3T
B.F.06.01.0031	TCMFB20/30–7 Left safety catch
B.F.06.01.0032	TCMFB20/30–7 Right
B.F.06.01.0019	HC 20–35HB

Tel: 0(212) 549 58 00 GSM: 0(546) 403 06 78 e-mail: satinalma@arslanforklift.com

Bayiliklerimiz...

Arslan Stack® Forklift

"Forklift Spare Parts Supplier"

www.arslanforklift.com

0(212) 549 58 00

O.S.B. Esenler Sanayi Sitesi 16 Blok No:9 Başakşehir/İstanbul

0(212) 549 58 00 - 01 0(546) 403 06 78

satinalma@arslanforklift.com

www.arslanforklift.com